Getting to know your handset

1. (Short press) My MEdia Menu

2. IM Key

3. Volume Control Keys

4. (Short press) Send Key/All calls

5. Speed Dial List

6. (Long press) Vibrate Mode/Ring Mode

7. OK Key

8. (Short press) Write Text Message

9. (Upper) Side Camera Key
   (Lower) Infrared Port

10. (Short press) Contact List

11. Voice Record Key

12. Charging Port (Charging Time: under 4 hours)

Selecting Functions and Options

Press the left soft key to access the available Menu.

Press the right soft key to access the available My Menu.

Take and Send Photo

1. Press the Camera key ( ).

2. In the preview screen, press the left and right navigation keys to adjust brightness, and press the up and down navigation keys to adjust zoom.

3. Press the Camera Key ( ) or (✗).

4. After capture, the photo is saved automatically.

To send it via MMS (Multimedia Message), press the left soft key [Send].

To go to preview screen, press the (✗) key.

Saving and Assigning Photos

Assigning a Wallpaper and Photo ID

1. Press the top icon on the Navigation Key, select Photo Gallery (5) and press OK.

2. Use the Navigation Key to select the photo you want to assign.

3. Press the Left Soft Key for Options:

To set as Wallpaper …

1. Select Set As Wallpaper and press OK.

To set as Photo ID …

1. Select Set As Photo ID and press OK.

2. Press the Right Soft Key for Zoom.

3. Position and crop the photo by using the following keys (options are dependent on resolution):

To zoom in, press the Left Soft Key. To zoom out, press the Right Soft Key.

To position the cropping rectangle on the desired portion of the photo, use the Navigation Key.

4. When you have the image cropped, press OK. Then press the Left Soft Key for Set.

5. Select a contact for this Photo ID and press OK.

Key tones

This menu option allows you to select a tone that the phone sounds when you press a key. You can select the keytones you want.

1. Press the left soft key [Menu].

2. Press   .