

PPV/FTG MPI CARD

LMT7Z9

ACCESSORY

MPI Card

For Pro:Idiom® TV Free To Guest (FTG)
and Pay-Per-View (PPV)



FULL LodgeNet® HD VIDEO ON DEMAND (VOD)
OR LodgeNet HD FREE-TO-GUEST
Complete "Plug and Play" solution

FTG ONLY (HD/DIGITAL AND ANALOG)
Essential for FTG (non-VOD and non-PPV)

Hotels to provide HD content

Configures LG commercial TVs for
channel mapping and commercial settings

*FTG Configuration Application software (provided by LG)
and cable (purchased separately) are required

MULTIPLE PROTOCOL INTERFACE (MPI) PASS THROUGH

Supports external VOD/PPV providers or other external
set-top boxes to control the LG TV

Pro:Idiom DECRYPTION

Provides control for Pro:Idiom encrypted programs which
enables Pro:Idiom decryption in the TV

OPTIONAL LG FTG MANAGEMENT APPLIANCE (FMA)

Remote management of FTG channel lineup (sold separately)



RoHS COMPLIANT

1-YEAR LIMITED WARRANTY
(parts/labor)

*For configuration software, manual, FTDI Chip cable (TTL-232R-5V-AJ),
and other details, go to www.LGcommercial.com/solutions/LMT7Z9.
The login and password will be available on the installation guide
packed with the product.

COMPATIBLE LG & ZENITH TVs

LCD DISPLAYS	LCD DISPLAYS	PLASMA DISPLAYS
L20V54S	LG3DCH	42PX7DC
L26W56	LX5 series	42PX8DC
L26W58	LX50 series	42PG60C
32LG3DC	32/37/42LG500H	
42LB5DC	32/37LG505H	
42LB50DC	32/37/42LG700H	
LH1 series		
LC5 series		
LC50 series		

www.LGcommercial.com



LG
Life's Good





figure 1. DATA FLOW-BETWEEN LMT7Z9 AND TARGET TV
Conditions of LMT7Z9: FTG mode from MPI pass thru or previously used in a different model TV in FTG mode.



figure 2. DATA FLOW-BETWEEN LMT7Z9 AND TARGET TV
Conditions of LMT7Z9: FTG mode previously used in a TV of the same model.



MODE AS SHIPPED

A "new" LMT7Z9 ships as an MPI pass thru interface card (default mode).

STAND ALONE FTG MODE

The LMT7Z9 in Free-To-Guest (FTG) mode provides LG/Zenith Pro:Idiom TV with a way to map logical channel numbers to physical or virtual channels. When a new LMT7Z9 is configured with a channel map by the FTG Configuration Application from a PC, it switches to FTG mode. When the TV is powered ON, a "banner" will appear briefly on the TV screen displaying the version of firmware on the LMT7Z9. Once in FTG mode, the Installer Menu settings of the TV, it is installed in, are copied into the LMT7Z9. If multiple TVs of the same model are to be configured with LMT7Z9 cards for the purpose of Free-To-Guest, set up a "master" TV with the desired Installer Menu settings before installing the new LMT7Z9. Each new LMT7Z9 card installed into the master TV and set to FTG mode will obtain the Installer Menu settings from the master. The configured LMT7Z9 card can be removed from the master and installed in a TV of the same model which will then be configured by that LMT7Z9 to be ready for operation.

FTG MODE: INSTALLED IN SAME MODEL

The Installer Menu settings in the LMT7Z9 are from the TV it was installed in last. When installed in a TV of the same model, these settings will be copied to the TV from the LMT7Z9 when power is applied to the TV. (see figure 1)

Any channel map that was on the LMT7Z9 will remain unchanged and will be the channel map the TV references to tune channels.

FTG MODE: INSTALLED IN DIFFERENT MODEL

The Installer Menu settings in the LMT7Z9 are from the TV it was installed in last. When installed in a TV of a different model, the settings of the TV will be copied to the LMT7Z9, overwriting settings on card, from the TV when power is applied to the TV. (see figure 2)

Any channel map that was on the LMT7Z9 will remain unchanged and will be the channel map the TV references to tune channels.

CONFIGURE LMT7Z9

Use FTG Configuration Application to configure the LMT7Z9. To download the Free-To-Guest application software and instruction manual, please visit this link.


URL www.LGcommercial.com/solutions/LMT7Z9

The login and password will be available on the installation guide packed with the product.


UPC: 7 19192 17656 0



MPI EXTENDER CARD



LMT7Z9 CARD



REMOVAL INSTRUCTIONS (current card)

1. Remove both retaining screws and partially pull out current card from MPI slot so that the RF cable can be disconnected.
2. Disconnect RF cable and gently pull out the current card.

INSTALLATION INSTRUCTIONS (LMT7Z9 card)

3. Partially slide the LMT7Z9 Card into the MPI slot.
4. Connect the RF cable.
5. Fully slide the LMT7Z9 in so that the card seats securely into the backplane connector.
6. Install retaining screws.
7. Configure LMT7Z9 with FTG Configuration Application.