

# decoy™

## Quick Start Guide



Headset Pairing



Bluetooth® Pairing



Getting Music



Playing Music



Taking a Picture/  
Recording a Video



[www.LGUSA.com](http://www.LGUSA.com)






# Getting to Know Your Phone




\*Customizable.


# Headset Pairing

Decoy comes with a detachable Bluetooth headset for hands-free conversations. Decoy's Bluetooth wizard walks you through the pairing process and gets you wireless in no time!

1. Push **up** with  to access the Bluetooth wizard.\*
2. Detach the headset by pressing the release button on top of the phone, then press  to continue.
3. Press and *hold*  on the headset until a solid blue light appears, indicating that the headset is in pairing mode. Press  on the phone to proceed.
4. The phone will synchronize with the headset. Press  when synchronization is complete.





*\*Once you have paired the Decoy headset, pushing **up** on  will instead open the Bluetooth menu.*

**Note:** You can connect with up to two Bluetooth devices at once on Decoy with one in standby.




# Bluetooth Pairing

The Decoy headset is only the beginning! Connect with other headsets, phones, computers, speakers, and more via Bluetooth. Never let cables slow you down again!

1. Set your Bluetooth accessory into pairing mode.\*
2. Push **up** with  to access the Bluetooth menu. If you have not already paired with the Decoy headset, you will be shown the Bluetooth wizard.
3. Select **Add New Device (1)**.
4. If Bluetooth is off, you'll be prompted to turn it on. Press  to search for the accessory.
5. Once your accessory is located, highlight the accessory and press  to pair.
6. Press  again to connect with the device.





*\*Refer to your Bluetooth accessory's user guide for information about initiating pairing mode and the passkey if asked (typically "0000"). If the accessory supports the headset/hands-free profile, your phone will automatically pair for you without having to input the passkey.*

**Note:** Bluetooth accessories sold separately.





# Getting Music

Get connected with the latest hits on the music scene. Access a vast library of music through the V CAST Music catalog and download the newest releases directly to your Decoy!

1. Press  to access the main menu, then select **Media Center (5) > Music & Tones (1) > V CAST Music (1)**.
2. Select a song from one of the categories and press  to buy it.
3. Press  to confirm your purchase.
4. Press  to download the song.
5. You can save the song to the phone's memory or to an optional memory card.\*




*\*Sold separately.*



**Note:** Refer to the user guide for information on syncing your music with Verizon I Rhapsody.





## Playing Music

Feel the rhythm and rock out with your favorite songs on Decoy! Listen to your songs anywhere, thanks to Decoy's fully functional music player.






1. Press  to access the main menu, then select **Media Center (5) > Music & Tones (1) > My Music (4)**.
2. Select a song from one of the categories to play.
3. Use the side **Volume Keys**   to adjust the volume when a song is playing.

**Note:** To turn on Music Only Mode (radio frequency off except Bluetooth), press  > **Media Center (5) > Music & Tones (1)**. Press the **Left Soft Key** for **Mode**, select **On**, and press .




# Taking a Picture/Recording a Video

Ever have trouble matching a name to a face? Worry no more because Decoy lets you snap a quick photo and assign it to a contact in your phone book. You can also let your creative side out and explore the possibilities of Decoy's camcorder!

1. To activate camera mode: Press the side  **Key**.  
To activate video mode: Press and *hold* .
2. Push **up** or **down** on  to adjust the brightness. Push **left** or **right** on  to zoom.\* To adjust other camera/video options, press the **Right Soft Key**.
3. Press  to take a photo or record a video.

*\*Camera setting of 1600x1200 pixels does not support zoom function.*

**Note:** You can record up to 30 seconds (for sending) or 1 hour (for saving) of video depending on available memory. Videos (under 5MB) can be set as wallpapers.



## Optional Accessories

Accessories for convenience and fashion are available at [www.VerizonWireless.com](http://www.VerizonWireless.com).



Bluetooth Stereo Speakers



Bluetooth Stereo Headset  
(HBS-200)



Vehicle Power Charger



Extended Battery (1,500 mAh)



Portable Stereo Speakers



Swivel Holster

©2008 LG Electronics, Inc. All rights reserved. Decoy™ is a trademark of Verizon Wireless. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license. All other trademarks are property of their respective owners. All phone images are simulated.