LG IMPRINT



Saving and Searching Contacts



Playing Music



Customizing My Menu



Taking a Picture

Bluetooth® Pairing









SIDES

- Navigation Key
 - ∧ Contact List
 - ∨ Messaging
 - > Applications Carousel < Applications Carousel
- Left Soft Key (Menu)
- Speakerphone Key
- Send Key
- Function/Vibrate Mode Key
- Shift Kev

- Space Key
- Music Key
- Microphone
- Symbols Key
- 11. Message Key 12. Enter Key
- 13. Clear & Back Kev
- 14. OK Key
- 15. Power/End Key
- 16. Clear & Back Kev

- 17. Right Soft Key (@metro)
- 18. Earpiece
- 19. Headset Jack
- 20. Volume Up/Down Keys
- 21. microSD™ Memory Slot
- 22. Camera Key
- 23. Micro USB Charging Port
- 24. Camera Lens
- 25. Speaker

Keep track of contact information with the searchable contact list.

Save a Contact

- From standby mode and with the slide open, press up on the Navigation Key to access your contact list.
- Press the Left Soft Key for New to create a new contact.
- 3. Use the keyboard to enter the contact's name and contact information
- 4. When you're ready, press or for Save.

Search Contacts

- From standby mode and with the slide open, press up on the Navigation Key to access your contact list.
- 2. Enter the first few letters of a contact's name with the keyboard. Your phone will skip ahead to the first contact that matches these letters.







Enjoy your favorite songs on your mobile phone! Access music files with the music player and enjoy them to their fullest with stereo headsets or speakers.

- With the slide open and a microSD card containing compatible music files in your phone, press on the keyboard.
- Press the 2 Key for All Songs (2) to view a list of all available songs.
- Highlight a song with the Navigation Key and pressfor Play.







Find your most used features in seconds with My Menu! You may assign up to 12 shortcuts to specific menus or applications.

Add a Feature to My Menu

- With the slide closed and the screen unlocked, press the Left Soft Key for Menu and select My Menu (8).
- Highlight a field labeled Unassigned and press or Set.
- 3. Select the category containing the menu item you wish to add with **®**. You may now select a menu item by highlighting it and pressing **®**.

Access a Feature via My Menu

1. From the My Menu screen, highlight a command or menu with the **Navigation Key** and press (**).







Take pictures on the fly with the integrated digital camera. Enjoy the flexibility of zoom, multishot, and a number of other customizable features.

- With the slide closed and the screen unlocked, press and hold to access the viewfinder.
- Use the Navigation Key and Right Soft Key to browse a number of customizable options and settings.*
- 3. When you're ready, press to take a photo.









*The zoom and multishot features are only available at 640×480 and 320×240 resolutions.

Tired of getting tied up with cables and plugs? Don't worry; *Bluetooth* wireless technology pairs your phone with a wide range of wireless devices and accessories!

- Before you begin, set your Bluetooth accessory into pairing mode.*
- 2. From standby mode and with the slide open, press the Left Soft Key for Menu and select Bluetooth (9).
- 3. Press ok for Paired Devices (1) and select Search with the Left Soft Key. If you are prompted to enable *Bluetooth*, do so by pressing ok for Yes (1). You may now select New Search (1).
- 4. Highlight your device with the Navigation Key, and then press for Pair. You may be prompted for a passcode.*
- 5. If you are prompted to connect to the device, press ox again.







*Refer to your *Bluetooth* accessory's user guide for information about initiating pairing mode and the passcode if asked (typically "0000"). If the accessory supports the headset/hands-free profile, your phone will automatically pair for you without having to input the passcode.

Note: Bluetooth accessories sold separately.



Bluetooth Headset (HBM-210)



Bluetooth Solar Speakerphone (HFB-500)



Vehicle Power Charger

Maximize your phone with these cutting-edge accessories at www.lgusa.com/imprint.

All materials in this guide including, without limitation, the design, the text, and any marks are the property of LG Electronics, Inc. Copyright 92:001 LG Electronics, Inc. ALL RIGHTS RESERVED LG is a registered trademark of LG Electronics, Inc. Features and specifications are subject to Anape without prior notice. The use of non-LG approved accessories will void the warranty and may result in damage to the phone, the phone exploding, or other danaperous conditions, microSD** is a trademark of SanDekt. The Bluetooth** word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics MobileCormy, USA, Inc. is under license. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately.

