



# ***muziQ***<sup>™</sup>

## Quick Start Guide



Using the  
Memory Card



Playing  
Music



Transmitting Music  
to FM Radio



Bluetooth®  
Pairing



Taking a Picture/  
Recording a Video



[www.LGUSA.com](http://www.LGUSA.com)

# Getting to Know Your Phone



## Using the Memory Card

Pack up to 64MB of your favorite music into your phone so you can play your tunes anywhere or store extra pictures and video for easy transfer to your PC.








1. Insert your microSD card into the memory port with the gold contacts facing up.
2. Connect the USB cable from the phone to the PC.
3. A USB Connection screen will appear. Select **Mass Storage (2)**.
4. Select **Yes (1)** to confirm that voice calls will be disabled.
5. The PC will recognize the phone as a **Removable Disk** under **My Computer**. Drag and drop music files into the Music folder or photos into the DCIM folder.
6. When done, press **END**. Confirm by selecting **Yes (1)**, then disconnect the cable.



**Note:** A 64MB microSD card is included.

# Playing Music


Muziq looks like a music player, and for good reason. Now you can kick back and chill to your own mixes or buy new tunes through Sprint—all with great stereo sound.

1. With the flip closed, press and *hold* the  **Key** on the right side of the phone to unlock the external touch controls.
2. Tap  to start the player.
3. Tap  or  to go to the next or previous song. Tap  or  to view the song list.
4. Tap  to pause/play the music. To exit the music player, open the flip and press **END** twice.

## Multitasking

Muziq can multitask (run up to 2 Java apps) while playing music in the background.



1. Press the **Music Key** on the right side of the phone to send the music player to the background or foreground.



## Transmitting Music to FM Radio






Got the ultimate sound system in your car or home? Play Muziq right through your FM radio and see how much power you can get out of this tiny package.

1. With the flip open, press the side **Music Key**.
2. Once a song is playing, press the **Right Soft Key** for **Menu** and select **Music Transmitter On (4)**.
3. Set your radio to 88.1 FM (the phone's default setting) to listen.
4. To change the transmit frequency, either press the **Right Soft Key** for **Input Freq** or use the Navigation Key to find a channel and press the **Left Soft Key** to transmit.



## Bluetooth® Pairing

Say goodbye to cord hassles with Bluetooth connectivity to a headset, speakerphone, portable speakers, or laptop. Great for hands-free talk, music, or exchanging contacts.

1. Set your Bluetooth accessory to pairing mode.\*
2. From standby mode, press , select **Tools (9)**, then **Bluetooth (6)**.
3. Press  when prompted to turn on Bluetooth. Select **Add New** and press  to search. The phone will now search for Bluetooth enabled devices (in pairing mode) within range.
4. Once the Bluetooth device has been found, highlight it and press .
5. Select **Add to Trusted (1)**.
6. Enter the pin code (typically “0000” – 4 zeroes) and press  to pair.\*





\* Refer to the user manual of your Bluetooth accessory to activate pairing mode and for the pin code.

**Note:** When using a Bluetooth stereo headset, streaming audio from Sprint TV is not supported.






## Taking a Picture/Recording a Video

Snap rich 1.3 megapixel photos or record long video clips so you can savor your favorite moments the instant they happen. Share the best ones immediately with friends.

1. To take a picture, press and *hold* the  **Key**. To record a video, short press , then choose **Camcorder (2)**.
2. Press **left** or **right** on the Navigation Key to adjust brightness and **up** or **down** for zoom.\* Press the **Right Soft Key** to adjust other camera/camcorder settings. Press the side **Music Key** to turn on the flash/video light.
3. Press  to take the picture or start recording. (Press  again to stop recording.)
4. To send your picture/video, press the **Right Soft Key** for **Options**, then **Send**.

\* Camera setting of 1280 x 960 does not support zoom function.

**Note:** To take self-portraits with the flip closed, press and *hold* the side  **Key** once to unlock the phone, and again to activate the camera. Press  or tap  to take the picture.



## Optional Accessories

Accessories for convenience and fashion are available at [www.LGUSA.com](http://www.LGUSA.com).



Bluetooth Stereo Speakers



Bluetooth Headset



Portable Stereo Speakers



Stereo Headset



Vehicle Power Charger



Carrying Case

©2007 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated.