

LG Apex™ | Quick Start Guide



PHONE SETUP



HOME SCREEN
THEMES



SOCIAL
NETWORKING



QWERTY
KEYBOARD



NAVIGATION



WIRELESS
SETTINGS



CUSTOMIZABLE
HOME SCREENS



ANDROID

lgusa.com/apex



Getting To Know Your Phone



- | | | |
|--------------------------------|---------------------------------|--------------------------|
| 1. Earpiece | 7. Power/Lock Key | 13. Camera Key |
| 2. Tempered Glass Touch Screen | 8. Search Key | 14. microSD™ Memory Slot |
| 3. Home Key | 9. Back Key | 15. Camera Lens |
| 4. Menu Key | 10. Proximity and Light Sensors | 16. Headset Jack |
| 5. Call Key | 11. Volume Up/Down Keys | 17. Flash |
| 6. Microphone | 12. Micro USB Charging Port | 18. Speaker |





QWERTY Keyboard



- 1. Back Key
- 2. Search Key
- 3. Alt Key
- 4. Caps/Shift Key

- 5. Vibrate Mode Key
- 6. Space/Symbols Key
- 7. Enter Key
- 8. Directional Key



- 9. OK Key
- 10. Menu Key
- 11. Home Key
- 12. Delete Key



Phone Setup

To get the most out of your Apex, sign into your Google Account, or set up an account if you don't have one, when you first power on the phone. You'll be able to use Gmail™, download applications from Android Market™, and more.

1. Begin by tapping the **Android icon**.
2. You may view a tutorial of your phone's features. Follow the on-screen prompts. Tap **Skip** to skip the tutorial.
3. If you already have a Google Account, tap **Sign in**. If you do not have one, tap **Create** and then follow the on-screen prompts to set up an account.
4. Slide open the keyboard and enter your username and password.
5. Tap **Sign in** and slide the keyboard closed.
6. Tap **Next** and then tap **Finish setup**.






Home Screen Themes

Apex has two home screen layout themes to choose from: Android Home (the default) and LG Home. Select your favorite and show off your style!

1. To switch to LG Home, begin by tapping .
2. Slide up to scroll down and tap **Themes**.
3. Tap **LG Home**.
4. To switch to Android Home, tap .
5. Slide up to scroll down and tap **Themes**.
6. Tap **Android Home**.






Customizable Home Screens



Apex has five panes for you to customize with your favorite applications and widgets. Organize your Apex to fit your lifestyle!

1. Swipe to a screen with blank space, and then press and hold an empty part of the screen.
2. Tap a category, and then select an item from the list.
3. You may need to remove an item before adding another one. To delete an item, press and hold it, drag it over  (it should turn red), and then release it.
4. Repeat steps 1 and 2 to add the new item.







Social Networking



Your favorite social networks are just a tap away with Apex. Check your Facebook®, MySpace™, and Twitter™ accounts right from your phone!

1. Begin by tapping .
2. Slide up to scroll down and tap **Facebook**.
3. Agree to the End-User License Agreement.
4. Enter the email address you use for Facebook.
5. Tap the **Password field** and enter your Facebook password.
6. Tap **Login**, and then tap **Finish**.







Navigation

Find your destination quickly and easily with Your Navigator Deluxe or with Google Maps. Google Maps provides spoken turn-by-turn directions showing real-time traffic and 360° views of your destination.

To Navigate with Google Maps

1. Tap  > **Maps** > **OK**.
2. Press the  **Key**, and then tap **Directions**.
3. Enter an address in the **End point field**, and then tap **Go**.
4. Tap **Navigate**, read the warning, and tap **Accept**.
5. If GPS is not enabled, you will be prompted to turn it on. Tap **OK**, and then tap **Use GPS satellites**.
6. Read the warning and tap **Agree**.
7. Tap **ON**, and then press the  **Key**.






Wireless Settings

Pair Apex with headsets, computers, and more via *Bluetooth*[®] wireless technology and rid yourself of cables and cords. Take advantage of wireless hotspots with Wi-Fi[®], or, when you want some time alone, enable Airplane mode to disable all wireless communications.

1. Begin by tapping the  **Key** and then tapping **Settings**.
2. Tap **Wireless & networks**.
 - Tap **Airplane mode** to disable/enable all wireless connections.
 - Tap **Wi-Fi** to enable/disable Wi-Fi.
 - Tap **Bluetooth** to enable/disable *Bluetooth* wireless technology.





Optional Accessories



Bluetooth Headset
(HBM-235)



Bluetooth Headset with Vehicle Power Charger (HBM-585)



Bluetooth Headset with Speakerphone/Solar Charging Cradle (HBM-810)



Bluetooth Stereo Headset
(HBS-700)



Vehicle Power Charger

Maximize your phone with these cutting-edge accessories at www.lgusa.com/apex

All materials in this guide including, without limitation, the design, the text, and any marks are the property of LG Electronics, Inc. Copyright © 2010 LG Electronics, Inc. ALL RIGHTS RESERVED. Features and specifications are subject to change without prior notice. LG is a registered trademark of LG Electronics, Inc. Apex™ is a trademark of LG Electronics, Inc. microSD™ is a trademark of SanDisk. Google and the Google logo are trademarks of Google Inc. Android is a trademark of Google Inc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics MobileComm, U.S.A., Inc. is under license. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately.



Mixed Sources

Product group from well-managed forests and other controlled sources and recycled wood or fiber

www.fsc.org Cert no. XXX-XXX-XXX
© 1996 Forest Stewardship Council

