



www.LGUSA.com

UX3300

Quick Start Guide



Changeable Faceplates



Speakerphone



Voice-Activated Dialing



Voice Memo Recorder



Text Messaging



Getting to Know Your Phone



*Customizable


Changeable Faceplates

Get a great new look for your phone in just seconds! The UX3300 comes with one striped blue and one silver faceplate in the box.



Removing a faceplate:

1. Press firmly at the **top center** of the faceplate.
2. Push **down** until the faceplate pops out.
3. **Remove** faceplate.



Replacing a faceplate:

1. Place desired faceplate approximately **1/4 inch** from the top of the phone.
2. Press **down** to lock sides in place.
3. Push **up** to lock tabs in place.



Speakerphone

Enjoy the convenience of hands-free conversation with a simple touch of one key.

1. From standby mode, press **up** on the Navigation Key.
2. “**Speaker On**” will appear and remain on the screen.
3. Press **up** on the key again to deactivate.
4. “**Speaker Off**” will appear on the screen.



Voice-Activated Dialing

You'll appreciate the safety and convenience of placing calls without dialing.

1. Press the **Left Soft Key** for **Menu** and select **Contacts** (1).
2. Select **Voice Dials** (6).
3. Press the **Left Soft Key** for **New**, select a contact and press **OK**.
4. Select the desired phone number and press **OK**.
5. Press **OK** to record the voice dial tag by following the phone's prompts.




Note: From standby mode, voice-activated dialing can be initiated by pressing the **Voice Dial Key** on the left side of the phone.

Voice Memo Recorder

Keep track of important personal information by recording up to 30 voice memos totaling 4 minutes.

1. From standby mode, press and *hold* the side **Voice Memo Key**.
2. Start recording after the tone.
3. Press the **Left Soft Key for Done** to stop recording.
By default, your message will be listed by date and time.
4. To play message, highlight the voice memo and press **OK**.
5. Press the **Left Soft Key to Play**.



Note: Recorded voice memos are stored in **Tools (4)** under **Voice Memo (3)**. You can even set voice memos as ringtones!

Text Messaging

Communicate discreetly with text messaging.

1. From standby mode, press **down** on the Navigation Key and select **New Message (2)**.
2. Press the **Left Soft Key** for **Contacts** and select a recipient from the **Contacts (1)**, **Recent Calls (2)** or **Recent Addresses (3)** menu, or use the keypad to enter a new e-mail address or phone number and press **OK**.
3. Select **Message** and press **OK**.
4. Enter the message using the keypad.
5. Press the **Right Soft Key** to insert quick-text.
6. Press **OK** once your message is complete.
7. Press the **Left Soft Key** to send.



Optional Accessories

Accessories for productivity, convenience and fashion are available at www.LGUSA.com.



Extended Li-Ion Battery
(1,700 mAh)



Carrying Case



Mobile Charger



Vehicle Power Charger



Portable Hands-Free Kit



Battery Wall Charger