

octane™



QUICK START GUIDE



QWERTY Keyboard



Social Networking



Mobile Email



3.2 MP Camera



Music Player



LG

Life's Good

www.lgusa.com/octane

Getting to Know Your Phone



FRONT



SIDES



BACK

1. Earpiece
2. External LCD
3. CONTACTS Key
4. OK Key
5. SEND Key
6. Voicemail Key
7. Vibrate Mode Key
8. PWR/END Key

9. Directional Key
^ My Music
v Events
> Bluetooth Menu
< Messaging
10. CLR Key/Voice
Commands Key
11. Camera/Video Key

12. Volume Keys
13. Headset Jack
14. microSD™ Slot
15. Accessory/Charger Port
16. Camera Lens
17. Flash



QWERTY Keyboard




1. Left Soft Key (Message)
2. Social Beat Key
3. New TXT Message Key
4. Favorites/SHIFT Key
5. Function Key
6. Vibrate Mode Key
7. Space/Voice Commands Key
8. Enter Key
9. CLR Key
10. Speakerphone Key
^ Mobile Web
v Events
> My Shortcuts*
< My Verizon
11. Directional Key
12. OK Key
13. SEND Key
14. PWR/END Key
15. Right Soft Key (Contacts)

*Customizable

Social Networking


Social Beat on the LG Octane provides single-application access to Facebook®, MySpace™, and Twitter™. Stay in touch with friends and family, and keep everyone updated on events as they happen!

1. From idle mode and with the flip open, press the **Social Beat Key** .
2. Select a social network. Steps may vary from this point.
3. Enter the email address and password associated with your social network, then select **Sign In**.



The Octane provides instant access to your favorite email providers. Compose messages in seconds with the QWERTY keyboard. Link your phone to your inbox and leave your laptop at home!

1. From idle mode and with the flip open, press the **OK Key**  (**MENU**), and then press **6** (**Mobile Email**).
2. You will need to download the free mobile email application. Press the **OK Key** .
3. To accept data charges if asked, press the **Left Soft Key** (**OK**).
4. Press the **OK Key**  to run the email application. Read the welcome and press the **OK Key**  (**Accept**).
5. Select an email provider from the list. The steps that follow may vary depending on your provider.
6. Enter your email address and password, and then press the **OK Key** .
7. Choose whether you want to receive push notifications, and then press the **Right Soft Key** (**Done**).



3.2 MP Camera

Take pictures on the fly with the integrated 3.2 megapixel camera/camcorder. Enjoy the flexibility of Intelligent Shot, Smile Shot, and a number of other convenient features.

1. From idle mode and with the flip open, press the **Camera/Video Key** .
2. Press the **Right Soft Key (Options)**.
3. Press **4 (Shot Mode)**.
4. Choose a shot mode. Smile Shot automatically takes a picture when a smile is detected. Panorama allows you to take three guided shots for a wide-area view. Intelligent Shot automatically adjusts to the surrounding conditions. Dual Display activates the external display for self-portraits.
5. Press the **Camera/Video Key**  to take a picture.




Enjoy your favorite songs without carrying an MP3 player! Download hit songs from V CAST Music with Rhapsody® and play them directly from your phone!

Get Music

1. From idle mode and with the flip open, press the **OK Key** **OK** (**MENU**), and then press **5** (**Media Center**).
2. Press **2** (**Music & Tones**), and then press **1** (**V CAST Music | Rhapsody**).
3. Browse the music catalog and follow the instructions to download songs right to your phone.

Play Music

1. From idle mode, press the **OK Key** **OK** (**MENU**), and then press **5** (**Media Center**).
2. Press **2** (**Music & Tones**), and then press **5** (**My Music**).
3. Press **1** (**All Songs**), and then press the **OK Key** **OK** (**PLAY**).





Bluetooth Headset
(HBM-230)



Bluetooth Headset
(HBM-570)



Bluetooth Headset with Vehicle
Power Charger (HBM-585)



Bluetooth Stereo Headset
(HBS-700)



Bluetooth Headset with
Speakerphone/Solar Charging
Cradle (HBM-810)



Vehicle Power Charger



Maximize your phone with these cutting-edge accessories at
www.lgusa.com/octane

All materials in this guide including, without limitation, the design, the text, and any marks are the property of LG Electronics, Inc. Copyright © 2010 LG Electronics, Inc. ALL RIGHTS RESERVED. LG is a registered trademark of LG Electronics, Inc. Features and specifications are subject to change without prior notice. Octane™ is a trademark of Verizon Wireless. microSD™ is a trademark of SanDisk. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics MobileComm, U.S.A., Inc. is under license. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately.



Mixed Sources
Product group well-managed
for its controlled source and
recycled wood or fiber
www.fsc.org Cert no. XXX-XXX-XXX
© 1996 Forest Stewardship Council

