



VOYAGER™

QUICK START GUIDE



MCDD0014801 (1.4) H

Voyager™ is a trademark of Plantronics, Inc. used under license by Verizon Wireless.

Getting to Know Your Phone



Steps in this guide are shown using the touch screen. Refer to the User Guide for more details.

QWERTY Keyboard



*Customizable

Using the Touch Screen

Touch Protection

The touch screen is automatically locked when the phone is closed or after the phone is inactive for 14 seconds (default).

Unlocking the Touch Screen

- Tap **Unlock icon**  .
– or –
- Slide the **Unlock Key**  on the left side of the phone downwards and release.



Using the Touch Screen

- Use the tip of your finger to touch the center of a touch key.
- It's not necessary to press hard. A light tap will do.
- Press and *drag* your finger **up** or **down** to scroll.
- A beep will sound when you've reached the top or bottom of a menu.
- Press the **Power/End Key** at any time to return to the idle screen.

Touch Screen Settings

- Tap **Menu icon** , **Settings & Tools**, then scroll down to **Touch Settings (8)** to adjust the touch screen's sound, vibration, and calibration.
- If the touch screen is not responding as you expect, calibrate the screen for touch accuracy.

Making & Answering a Call

Calling Someone in Your Contacts List

1. Unlock the phone.
2. Tap **Contacts icon** , then **A-I J-P Q-Z */#** for a quick jump, and choose a contact.
3. Tap the phone number you want to dial.

Dialing a Call

1. Unlock the phone.
2. Tap **Phone icon** , then use the virtual keypad to enter a phone number.
3. Tap **Call** or press the **Send Key**.



Checking Voicemail

1. Unlock the phone.
2. Tap **Phone icon** , then tap and *hold* **1** .
3. Tap **Unlock icon** , then enter your password.

Answering Calls

Press the **Send Key** or tap **Unlock icon** , then **Answer**.

Note: If the phone is ringing or vibrating, press the **Volume Keys** to quiet the phone.




Subscribing & Watching TV

1. Unlock the phone, and tap the center of the touch screen to access the **Shortcut Menu**. Tap **Mobile TV** .
2. Rotate phone clock wise.
3. An introduction video clip will play (for the first time).
4. Tap **Subscribe Now**. Review base package and tap **Continue**.
5. Read the Terms and Conditions and tap **Agree**. Confirm selection and tap **Submit**.
6. From the V CAST screen, tap **Program Guide icon**  on the top left corner. Tap the show you want to watch.



Browsing the Net

1. Unlock the phone.
2. Tap the center of the touch screen to access the **Shortcut Menu**.
3. Tap **Browser** .
4. Rotate phone clock wise.
5. Choose a category or tap **WWW**, then  to type in a specific web site using the virtual keyboard.
6. On a web page, drag **up** or **down** to scroll, or tap on a section in the thumbnail for a quick jump.




To activate the thumbnail feature:

Tap **Menu** > **Settings (9)** > **Display (2)** > **Thumbnail (1)** > **On** or **Auto**.

Note: Browser supports full screen mode, sending URL via text messages, auto-complete feature, and Spanish input for text and browser search, other than URL.

Getting Music


1. Unlock the phone.
2. Tap the center of the touch screen to access the **Shortcut Menu**.
3. Tap **My Music** .
4. Rotate phone clock wise.
5. Tap **Shop** to access V CAST Music.
6. Select a song from one of the categories and tap **Buy** to purchase it.
7. Tap **Buy This Song** to confirm purchase.
8. Tap **Download Now** to download the song. Downloaded songs are stored in **My Music**.



Note: Refer to the User Guide or Quick Reference Guide for instructions on how to sync music from PC to phone.

Playing Music

1. Unlock the phone.
2. Tap the center of the touch screen to access the **Shortcut Menu**.
3. Tap **My Music** .
4. Rotate phone clock wise.
5. Select a song from one of the categories to play.
6. Use the **Volume Keys** to adjust volume when a song is playing.
7. Press the **Power/End Key** to exit the music player.




Note: With the flip closed, if you answer a call while playing music, browsing the net, watching TV/video, or using VZ Navigator,SM and end the call by pressing the external **End Key**, the touch screen will lock. Unlock the phone by sliding the **Unlock Key**  downwards.

Taking a Picture/Recording a Video

1. Unlock the phone.
2. To activate camera mode: Press the **📷 Key** located on the left side of the phone.
To activate video mode: Press and *hold* the **📷 Key**.
3. Rotate phone clock wise.
4. Use the **Volume Keys** to zoom.* Tap **Options** to adjust other camera/video options.
5. Press the **📷 Key** to take a photo or record a video.
6. You can save, send or erase the photo/video.

**Camera setting of 1600x1200 pixels does not support zoom function.*





Bluetooth® Pairing

1. Set your Bluetooth accessory into pairing mode.*
2. Unlock the phone.
3. Tap the center of the touch screen to access the **Shortcut Menu**.
4. Tap **Bluetooth** .
5. Tap **Add New Device (1)**.
6. If Bluetooth is set to off, you will be prompted to turn it on. Tap **Yes**.
7. Tap **OK**, and the phone will now search for the accessory. Once found, tap the accessory to pair.*
8. Tap **Yes** to connect with the device.

**Refer to the user manual of your Bluetooth accessory to activate pairing mode and for the passcode if asked (typically "0000" - 4 zeroes). If the accessory supports the headset/hands-free profile, your phone will automatically pair for you without having to input the passcode.*

Note: Bluetooth accessories sold separately.



Optional Accessories

Accessories for convenience and fashion are available at www.VerizonWireless.com.



Bluetooth Headset




Bluetooth Stereo Headset



Bluetooth Stereo Speakers



Portable Stereo Speakers



Extended Li-Polymer Battery
(1,500 mAh)



Swivel Holster with Kickstand

©2007 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.