

Quick Start

3.5 mm
headset
jack

IR (infrared)
LED

Camera lens



Microphone

Micro USB
charging
port

Laser
Auto Focus

Volume
keys



Camera lens

Flash

Power/lock
key



LG G Vista





AT&T Ready2Go

Set up your device quickly and easily by using Ready2Go:

- Set up Email accounts and Facebook®
- Sync your contacts and calendar
- Connect to Wi-Fi®

You can use Ready2Go when you first activate your device or open it later from the app tray. The wizard will guide you through the setup process.



Note: To skip the wizard, tap **not now** > **exit**. To return to the wizard from the home screen, tap  > .

Customize Your Phone

Home Screen

- ① Press and hold an empty spot on a home screen and choose a category:
 - **Apps:** Add shortcuts from the app tray.
 - **Widgets:** Add dynamically updating widgets.
 - **Wallpapers:** Change your wallpaper.
- ② To move an item, press and hold it and drag it to a new location. To delete it, drag it to **Remove**.

Your Sounds

From the home screen, press and hold  and tap **All settings > Sound > Volumes**. You can change your ringtones, set notification sounds, and adjust your touch feedback options.




Touch Screen


KnockON

KnockON is enabled at default. Double tap an empty part of the screen or the top bar to lock the phone. Double tap again to wake it.

Notifications Panel



Camera and Video




Share Photos

- ① Tap the thumbnail in the lower right of the screen.
- ② Tap .
- ③ Tap an option and follow on-screen instructions.

Transfer Music and Pictures

- ① Connect your device to your computer with a USB cable. Steps may vary depending on your operating system.
- ② You may be prompted to install PC programs. Tap **OK > Media sync (MTP)**.
- ③ On your PC, choose **Open device to view files** using Windows Explorer.
- ④ Your phone will appear as another hard drive on your computer. Click on the drive to view it.
- ⑤ Drag and drop your files* into the corresponding folders, such as Music, Movies, or Pictures. You can also transfer files from your PC to your phone.
- ⑥ When you're finished, swipe down on top of the screen. Tap **Media device (MTP) > Charge phone**. You may now unplug your device.



*Files must be Digital Rights Management (DRM) free.




Calls and Voicemail

Visual Voicemail

View your voicemail messages as a list in your mailbox and play them in the order you like.


From the home screen, tap  > .

Make a Call



Note: To reset your voicemail password, go to att.com/resetvm.

Text Messaging



Please don't text and drive.

Messaging rates apply.

Email



View folders and additional email accounts

Refresh your inbox

Compose a new email

Access settings and additional options


Choose a recipient from your contact list

Attach a picture or other file

Send your message

Note: Contact your IT administrator to help set up your corporate Microsoft® Exchange account.

Web





Note: To disable the Browser Bar, swipe up on  >  > **Toolbar**.

Input Language

Change Device and Input Language

- ① From the home screen, press and hold  and tap **All settings > General > Language & input**.
- ② To change the device language, tap **Language**.
- ③ To change the keyboard input language, tap  next to the desired keyboard.
- ④ Tap **Input language and keyboard layout**.
- ⑤ Tap a language to select it. You can change languages by tapping  when you have a keyboard open, for instance while typing a text message.



Knock Code™

Get direct access to the home screen while keeping your phone secure.

Setup

- ① From the home screen, press and hold  and tap **Lock screen settings > Select screen lock > Knock Code > Next**.
- ② Follow the on-screen prompts to set up a Knock Code and backup PIN.

Use


- When the screen is dark, enter your Knock Code anywhere on the screen.
- If you enter your Knock Code incorrectly 5 times, you'll be prompted to enter your backup PIN.



Dual Window

Interact with two apps at once. To launch Dual Window, press and hold .


- Tap to open your two most recently used apps
- Drag an app to the top and bottom of the screen
- Drag to adjust window size



The image illustrates the steps to launch and use Dual Window on an Android phone. On the left, the home screen shows the weather and time (12:00 PM, Sat, Aug 30). A recent apps menu is open, displaying icons for Recent, Browser, Messaging, Email, Gallery, Chrome, YouTube, Maps, Hangouts, and Gmail. An orange line points from the text 'Tap to open your two most recently used apps' to the Recent apps menu. Another orange line points from the text 'Drag an app to the top and bottom of the screen' to the Recent apps menu. On the right, the phone is in Dual Window mode. The top window is the Messages app, showing a conversation with Julie Crawford and a photo of a lake. The bottom window is the Camera app, showing a grid of photos. An orange line points from the text 'Drag to adjust window size' to the bottom edge of the Messages window.

Mini View


Enable Mini View for one-handed usage of the LG G Vista.



AT&T DriveMode®



When your vehicle is in motion, automatically respond to incoming calls, texts, and emails.



AT&T DriveMode is free to AT&T customers. Standard data and messaging rates apply to auto-reply messages.



Wi-Fi and *Bluetooth*[®]

Connect to Wi-Fi

- ① From the home screen, press and hold  and tap **All settings** > **Networks** > **Wi-Fi**.
- ② Tap  to turn on Wi-Fi.
- ③ Tap a network name. Enter a password if required and then tap **Connect**.

Use *Bluetooth*

- ① From the home screen, press and hold  and tap **All settings** > **Networks** > **Bluetooth**.
- ② Tap  to turn on *Bluetooth*.
- ③ The LG G Vista will automatically search for devices. Tap a device to pair. See the *Bluetooth* device's user manual for more information on pairing.



Network Indicators

Your 4G LTE wireless device will indicate which of the AT&T wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds.

 **4G LTE:** Connected to the AT&T 4G LTE network.

 **4G:** Connected to the AT&T HSPA+ network. The AT&T HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. 4G availability is increasing with ongoing backhaul deployment.


 **E:** Connected to the AT&T EDGE/2G network.

Actual data upload and download speeds depend on various factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at: wireless.att.com/learn/articles-resources/wireless-terms.jsp, your AT&T Wireless Customer Agreement, Section 3.2 "Where and How Does AT&T Service Work?"

4G LTE not available everywhere. LTE is a trademark of ETSI. Learn more at att.com/network.

Google Play™

Once you have set up your Google™ account, you can download apps, music, movies, and more from the Play Store.



Notes:

- To purchase a paid app, you will need to set up a payment method with Google Wallet™.
- You may want to download apps over Wi-Fi to save on your data plan usage.

AT&T Services

AT&T offers a multitude of apps designed to make your everyday life easier.



myAT&T: Track your usage, review and pay your bill, and update your data plan services.



AT&T Mobile Hotspot: Share your mobile network data connection with other Wi-Fi devices.



AT&T Locker™: Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.



AT&T Mobile Locate: Back up contacts and media, locate a lost device, and get device support.



AT&T Navigator®: Get voice-guided, turn-by-turn driving directions and traffic updates.



Mobile TV: Watch LIVE and on-demand mobile TV.



AT&T Smart Wi-Fi: Maximize your battery performance and data plan, simplify access to AT&T Hot Spots and Wi-Fi networks, automate your Wi-Fi connections, and track your data usage.

Data rates may apply. Mobile TV and AT&T Navigator require a separate subscription. Mobile TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Watch capability available for select content, requires Wi-Fi connection, and is available for viewing for limited time periods.

Find More Information

On Your Phone

- Tutorials and videos: **Apps > DeviceHelp**
- Access your account: **Apps > myAT&T**

On the Web

- Tutorials and videos: **att.com/DeviceHowTo**
- Manage your wireless account, including suspending service if your phone is stolen: **att.com/MyATT**

Give Us a Call

- 1-800-331-0500
- 611 from any AT&T wireless phone

Accessories

- **att.com/WirelessAccessories**
- Visit your AT&T store

Portions copyright © 2014 LG Electronics. LG, LG Life's Good, and the LG logo are registered trademarks of LG Corp. Portions © 2014 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks contained herein are the property of their respective owners.