


# Quick Start

Status LED  
Camera lens  
Earpiece



3.5 mm headset jack  
Micro USB charging port

Camera lens  
Laser auto focus  
Volume keys  
Flash  
Power/lock key



**LG G3 Vigor™**





# AT&T Ready2Go



Set up your device quickly and easily by using Ready2Go:

- Set up Email accounts
- Sync your contacts
- Connect to Wi-Fi®

You can use Ready2Go when you first activate your device or open it later from the app tray. The wizard will guide you through the setup process.



Note: To skip the wizard, tap **not now** > **exit**. To return to the wizard from the home screen, tap  > .

# Customize Your Phone

## Home screen

- ① Press and hold an empty spot on a home screen and choose a category:
  - **Apps:** Add shortcuts from the app tray.
  - **Widgets:** Add dynamically updating widgets.
  - **Wallpapers:** Change your wallpaper.
- ② To move an item, press and hold it and drag it to a new location. To delete it, drag it to **Remove**.

## Your Sounds

From the home screen, press and hold  and tap **All settings** > **Sound**. You can change your ringtones, set notification sounds, and adjust your touch feedback options.



# Touch Screen

## KnockON

KnockON is enabled at default. Double-tap an empty part of the screen or the top bar to lock the phone. Double-tap again to wake it.

## Notifications Panel


Tap to adjust your Quick Settings

Access all settings


Tap to respond to a notification

Remove all notifications

Swipe left or right to remove a notification



# Camera, Video, and Sharing Photos




## Share photos

- ① Tap the thumbnail in the lower right of the screen.
- ② Tap .
- ③ Tap an option and follow on-screen instructions.

# Transfer Music and Pictures

- ① Connect your LG G3 Vigor™ to your computer with a USB cable. Steps may vary depending on your operating system.
- ② You may be prompted to install PC programs. Tap **OK > Media sync (MTP)**.
- ③ On your PC, choose **Open device to view files** using Windows Explorer.
- ④ Your phone will appear as another hard drive on your computer. Click on the drive to view it.
- ⑤ Drag and drop your files\* into the corresponding folders, such as Music, Movies, or Pictures. You can also transfer files from your PC to your phone.
- ⑥ When you're finished, swipe down on top of the screen. Tap **Media device (MTP) > Charge phone**. You may now unplug your device.



\*Files must be Digital Rights Management (DRM) free.

# Calls and Voicemail




## Visual Voicemail

View your voicemail messages as a list in your mailbox and play them in the order you like.

From the home screen, tap  > .

## Make a Call




**HD** HD Voice Capable™ - Clear conversations and reduced background noise.

LG G3 Vigor supports AT&T HD Voice which enables background noise reduction and crisp audio quality when both callers are using AT&T HD Voice compatible phones within the AT&T HD Voice coverage area and have HD Voice provisioned on their account. HD Voice has limited availability in select markets. For further details on AT&T HD Voice and service restrictions, visit [att.com/hdvoice](http://att.com/hdvoice).

Note: To reset your voicemail password, go to [att.com/resetvm](http://att.com/resetvm).

# Text Messaging




*Please don't text and drive.*

Messaging rates apply.

# Email



- View folders and additional email accounts
- Refresh your inbox
- Compose a new email
- Access settings and additional options
- Choose a recipient from your contact list




Attach a picture or other file

Send your message

Note: Contact your IT administrator to help set up your corporate Microsoft® Exchange account.

# Web





Note: To disable the Browser Bar, tap  >  > **Toolbar**.

MBM64538901 (1.0)

# Input Language

## Change Device and Input Language

- ① From the home screen, press and hold  and tap **All settings** > **General** > **Language & input**.
- ② To change the device language, tap **Language**.
- ③ To change the keyboard input language, tap  next to the desired keyboard.
- ④ Tap **Input language and keyboard layout**.
- ⑤ Tap a language to select it. You can change languages by tapping  when you have a keyboard open, for instance while typing a text message.



# QuickMemo+




## Create a Memo with a Location Reminder

- ① From the home screen, tap  > **QuickMemo+**.
- ② Tap  to begin a new memo, and then enter your message.
- ③ Tap  to save the memo.
- ④ To create an location-based reminder alert, tap the saved memo > **Add reminder** > **Location reminder**.
- ⑤ Enter the location in the Search location field and tap **Done**.
- ⑥ Tap the location and then tap  to save the reminder alert.

Tap to write the memo with your finger

Tap to use the keyboard to type a memo






Tap to erase the memo

Tap to save the memo

# QSlide Function

The QSlide function enables an overlay on your phone's display for easy multitasking. You can open two QSlide apps on top of a third app from your library.

## QSlide apps



# Knock Code™

Get direct access to the home screen while keeping your phone secure.

## Setup

- ① From the home screen, press and hold  and tap **Lock screen settings > Select screen lock > Knock Code > Next**.
- ② Follow the on-screen prompts to set up a Knock Code and backup PIN.

## Use


- When the screen is dark, enter your Knock Code anywhere on the screen.
- If you enter your Knock Code incorrectly 5 times, you'll be prompted to enter your backup PIN.



# AT&T DriveMode®



When your vehicle is in motion, automatically respond to incoming calls, texts, and emails.



AT&T DriveMode is free to AT&T customers. Standard data and messaging rates apply to auto-reply messages.



# Wi-Fi and Bluetooth®

## Connect to Wi-Fi

- ① From the home screen, press and hold  and tap **All settings** > **Networks** > **Wi-Fi**.
- ② Tap  to turn on Wi-Fi.
- ③ Tap a network name. Enter a password if required and then tap **Connect**.

## Use Bluetooth

- ① From the home screen, press and hold  and tap **All settings** > **Networks** > **Bluetooth**.
- ② Tap  to turn on *Bluetooth*.
- ③ The LG G3 Vigor will automatically search for devices. Tap a device to pair. See the *Bluetooth* device's user manual for more information on pairing.



# Network Indicators

Your 4G LTE wireless device will indicate which of the AT&T wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds.

 **4G LTE:** Connected to the AT&T 4G LTE network.

 **4G:** Connected to the AT&T HSPA+ network. The AT&T HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. 4G availability is increasing with ongoing backhaul deployment.


 **E:** Connected to the AT&T EDGE/2G network.

Actual data upload and download speeds depend on various factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at: [wireless.att.com/learn/articles-resources/wireless-terms.jsp](http://wireless.att.com/learn/articles-resources/wireless-terms.jsp), your AT&T Wireless Customer Agreement, Section 3.2 "Where and How Does AT&T Service Work?"

4G LTE not available everywhere. LTE is a trademark of ETSI. Learn more at [att.com/network](http://att.com/network).

# Google Play™ Store

Once you have set up your Google™ account, you can download apps, music, movies, and more from the Play Store.



## Notes:

- To purchase a paid app, you will need to set up a payment method with Google Wallet™.
- You may want to download apps over Wi-Fi to save on your data plan usage.

# AT&T Services

AT&T offers a multitude of apps designed to make your everyday life easier.



**myAT&T:** Track your usage, review and pay your bill, and update your data plan services.



**AT&T Mobile Hotspot:** Share your mobile network data connection with other Wi-Fi devices.



**AT&T Locker™:** Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.



**AT&T Mobile Locate:** Back up contacts and media, locate a lost device, and get device support.



**AT&T Navigator®:** Get voice-guided, turn-by-turn driving directions and traffic updates.



**Mobile TV:** Watch LIVE, on-demand, and downloadable mobile TV.



**AT&T Smart Wi-Fi:** Maximize your battery performance and data plan, simplify access to AT&T Hot Spots and Wi-Fi networks, automate your Wi-Fi connections, and track your data usage.

Data rates may apply. Mobile TV and AT&T Navigator require a separate subscription. Mobile TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection, and is available for viewing for limited time periods.

# Find More Information

## *On your phone*

- Tutorials and videos: **Apps > DeviceHelp**
- Access your account: **Apps > myAT&T**

## *On the Web*

- Tutorials and videos: **att.com/DeviceHowTo**
- Manage your wireless account, including suspending service if your phone is stolen: **att.com/MyATT**

## *Give us a call*

- 800-331-0500
- 611 from any AT&T wireless phone

## *Accessories*

- **att.com/WirelessAccessories**
- Visit your AT&T store

Portions © 2014. LG, LG Life's Good, and the LG logo are registered trademarks of LG Corp. G3 Vigor is a trademark of LG Electronics, Inc. Portions © 2014 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks contained herein are the property of their respective owners.

Printed in China