

QUICK START GUIDE


LG G5™



MBM65422901 (1.0)

U.S. Cellular®
Customer Care:
1-888-944-9400

Parts overview




- ❶ Back-Facing Camera Lens
- ❷ Power/Lock Key, Finger Print Sensor
- ❸ Nano-SIM /microSD Card Tray
- ❹ Volume Keys
- ❺ Module Eject Key
- ❻ Module
- ❼ Charger/USB port (C-type)

Removing or inserting the battery

Removing the battery

- ❶ Press the module eject key to partly eject the module from the device.




- ❷ Grab the middle of the ejected module and pull it out.



Removing or inserting the battery

- ❸ Hold the battery and module with both hands and separate them from one another in an outward arc (as indicated below) to disconnect the battery terminals.




NOTE

- This device is supplied with the battery inserted. When using the device for the first time, check the battery level and fully charge the battery before using the device if necessary.

Removing or inserting the battery

Inserting the battery

- ❶ Align the arrows on both the battery and the module and firmly connect the battery terminals to the module.



- ❷ Align the battery with the lower edge and carefully slide the module back into the device.

NOTE

- Never press the module eject key when inserting the module into the device.
- When inserting the battery into the device, make sure the battery is attached to the module.


All materials in this QSG including, without limitation, the design, the text, and any marks are the property of LG Electronics USA, Inc. Copyright © 2016 LG Electronics USA, Inc. ALL RIGHTS RESERVED. LG, LG Life's Good and the LG logo are registered trademarks of LG Corp. Google and Android are trademarks of Google Inc. Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide. Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance. All other trademarks and copyrights are the property of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately. All features, functionality, and other product specifications are subject to change.

Visit www.uscellular.com to view the user guide and more information.

Some content and illustrations may differ from your device depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.



Installing the SIM card and memory card



NOTE

- Always use a Nano-SIM card supplied by the your service provider.

Precautions when using the device

- Failure to follow the instructions provided in your Quick Start Guide may result in damage to your product or personal injury.
- When replacing the battery, take extra care to ensure that no foreign substance or water enters the device.
- Do not expose your device to moisture or hot and humid environments.
- Do not expose the inside of your device to water and do not insert foreign objects into the battery compartment.
- After removing the module, put it back into the device as soon as possible to avoid damage to the device's interior.
- Do not forcefully separate the module without pressing the module eject key.
- Never remove the module when the device is in use.
- Do not insert a module from another device that is not compatible with your device's service provider and service area.
- Be careful not to hurt your hands when inserting or removing the module.
- Follow the instructions contained in your device manuals to ensure the battery and module are inserted correctly. Failure to insert the battery and module correctly may result in damage to the device or device malfunction.

Precautions when using the device

- Only use the USB cable and charger provided with your device. The use of third party USB accessories may damage the device and void the manufacturer's limited warranty.

Important information about the device

- Device apps and services are subject to change or cancellation without notice, depending on the provider's situation and the software version.
- When the device is turned on for the first time, initial configuration takes place. The first booting time may be longer than usual.

Read before use

- The appearance and specifications of the device are subject to change without notice.
- Do not use LG products for other purposes than those originally intended. Using non-certified apps or software may damage the device and this is not covered by warranty.