

QUICK START GUIDE

LG ENVOY™ II

U.S. Cellular® Customer Care:
1-888-944-9400



LG

Life's Good

Getting to Know Your Phone





Calls

LG Envoy™ II's large keypad makes dialing phone numbers quick and easy.

Make a Phone Call

1. From the home screen, begin dialing a number or start spelling the name of the desired contact.
2. Press **SEND** to call the number or highlight the contact you wish to call and press **OK**.





Messages

When you need to communicate quickly and privately, use text messaging.

Send a Message

1. From the home screen, press the **Left Soft Key** for **Message**.
2. Select **New Text Message (1)**.
3. Enter the recipient's number or press the **Right Soft Key** for **Options** to access your contact list.
4. Scroll down to the text field, enter your message, and then press **OK** for **Send**.

NOTE Please don't text and drive.



Personalize



Customize your phone by changing ringtones and alert sounds for a more personal touch.

Adjust Volume

To adjust the master volume, from the home screen, press the **Volume Up/Down Keys**.

Change Ringtone

1. From the home screen, press **OK** for **Menu**.
2. Select **Settings (9) > Sound (1) > Ringtones (1) > All Calls (1) > Default (2)**.
3. Highlight a ringtone and press the **Left Soft Key** for **Set**.
4. To adjust alert sounds, select **Message Alerts (3)** in the **Sound Settings** menu, choose **All Messages (4) > Default (2)** and follow step 3.





Contacts

Envoy II has plenty of space to store your contacts' information.

Add a Contact



1. From the home screen, press the **Right Soft Key** for **Contacts**.
2. Press the **Left Soft Key** for **New**.
3. Enter the contact's information and press **OK** for **Save**.



My Contacts Backup

Back up your mobile contacts to your online address book.




1. From the home screen, press **OK** for **Menu**.
2. Select **My Contacts Backup (0)**.
3. Press the **Left Soft Key** twice.
4. Press the **Left Soft Key** to confirm your phone number.
5. Enter a PIN. You'll need it to manage your account online. Press the **Left Soft Key** for **OK**.
6. Press the **Left Soft Key** for **OK**.
7. Press the **Left Soft Key** for **Yes** to back up your contacts.
8. Press **OK**.




Camera

Capture every moment with the 1.3 megapixel camera.

Take a Photo

1. From the home screen, press .
2. You may adjust settings such as white balance and brightness. Press  or  to take a photo.
3. To save your photo, select **View (3)** and press the **Left Soft Key** for **Save**.




Browsing

Browse the web with ease on Envoy II.

Browse the Web

1. From the home screen, press **OK** for **Menu**.
2. Select **Browser (7)**.
3. If prompted, press **OK** for **Yes (1)**.
4. Press the **Right Soft Key** for **Menu** and select **Go To URL (5)**.
5. Enter a web address, scroll down to **Go**, and press **OK**.
6. To exit the browser, press **END**.




Browsing (continued)

Add bookmarks for quick access to frequently visited websites.

Add and Use Bookmarks

1. Access the browser and navigate to a site you wish to bookmark.
2. To add a bookmark, press the **Right Soft Key** for **Menu** and select **Bookmarks (4)**.
3. Press the **Left Soft Key** for **Mark Site**, scroll down to **Save**, and press **OK**.
4. To access a bookmarked site, press the **Right Soft Key** for **Menu** and select **Bookmarks (4)**.
5. Scroll down to the desired site and press **OK**.



Customize

Personalize your Envoy II by changing the wallpaper and home screen banner.



1. From the home screen, press **OK** for **Menu**.
2. Select **Settings (9) > Display (2)**.

Change Wallpaper

1. From the **Display Settings** menu, select **Wallpaper (1)**.
2. Choose from default images or your own photos.
3. Highlight an image and press the **Left Soft Key** for **Set**.

Change Banner

1. From the **Display Settings** menu, select **Banner (2)**.
2. Scroll to the text field, enter a new banner, and press **OK** for **Save**.



Apps

Download applications and games from easyedge.

Download Applications

1. From the home screen, press **OK** for **Menu**.
2. Press **OK** for **easyedge (5)**.
3. Highlight a category and press **OK**.
4. Follow the prompts to download content.





Bluetooth®

Connect to headsets, computers, and more via *Bluetooth* wireless technology.

Connect to a Device

1. Place the *Bluetooth* device you wish to pair with in pairing mode. From the home screen, press **OK** for **Menu**.
2. Select **Settings (9) > Bluetooth (5) > Paired Devices (1)**.
3. Press the **Left Soft Key** for **Search**.
4. Select **Yes (1) > New Search (1)** to turn on *Bluetooth* and begin searching for devices.
5. Highlight a device name and press **OK** for **Pair**.
6. Select **Yes (1)** to connect to the device.



All materials in this QSG including, without limitation, the design, the text, and any marks are the property of LG Electronics USA, Inc. Copyright © 2013 LG Electronics USA, Inc. ALL RIGHTS RESERVED. LG and the LG logo are registered trademarks of LG Corp. Envoy is a trademark of LG Electronics USA, Inc. The *Bluetooth*® word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc. and any use of such marks by LG Electronics USA, Inc. is under license. **easyedge**™ is a service mark of U.S. Cellular. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately. All features, functionality, and other product specifications are subject to change.



LG

Life's Good

<http://www.lg.com/us>

P/N. XXXXXXXXXXXX

Printed in China