


\*Bottom of recessed box needs to reside below power cable and above bottom of the TV.

\*Recessed Box without flange, sold separately, must be utilized to achieve a no gap solution between the wall and TV.






\*Bottom of recessed box needs to reside below power cable and above bottom of the TV

\*Recessed Box without flange, sold separately, must be utilized to achieve a no gap solution between the wall and TV.





Example of cable management track




OLED65GX referenced in this image

\*Red marked area is for reference only. Recessed box, sold separately, will vary in size and location depending on project.

\*Bottom of recessed box needs to reside below power cable and above bottom of the TV

\*Recessed Box without flange, sold separately, must be utilized to achieve a no gap solution between the wall and TV.






\*Bottom of recessed box needs to reside below power cable and above bottom of the TV

\*Recessed Box without flange, sold separately, must be utilized to achieve a no gap solution between the wall and TV.






\*Bottom of recessed box needs to reside below power cable and above bottom of the TV.

\*Recessed Box without flange, sold separately, must be utilized to achieve a no gap solution between the wall and TV.





\*Bottom of recessed box needs to reside below power cable and above bottom of the TV

\*Recessed Box without flange, sold separately, must be utilized to achieve a no gap solution between the wall and TV.

