

AS OF  
**SEPT  
2022**

**This quick reference guide to cooking accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.**

**Step 1** Find your model number in this guide. Model numbers that contain an underscore (\_) are available in multiple colors. For example, LTGL6937\_ comes in both Stainless Steel (LTGL6937F) and Black Steel (LTGL6937D). LSGS6338F does not have the underscore as it only comes in Stainless Steel. Be sure to confirm availability and ordering of your color choice.

**Step 2** Read the information on required and optional accessories to determine your needs and prepare yourself by knowing the answers to the following questions.

- Gas or electric appliance?
- If purchasing a gas range or cooktop, is your home natural gas (NG) or liquid propane (LP)?
- Do you have the required electrical supply and an adequately sized circuit breaker?
- If installing an over-the-range microwave or hood, have you planned for venting?

**Step 3** Identify the items you need to purchase for your cooking appliance. Items with a check box need to be purchased separately.

**Where to Buy?**

**Required Accessories**

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.\*

**Optional Accessories**

Purchase by clicking the LG parts & accessories button\* or call 1-800-243-0000.

**LG Parts & Accessories**

**Contents**

- Slide-In Ranges** . . . . . 2-3
- Freestanding Ranges** . . . . . 4-5
- Over-the-Range Microwaves** . . . . 6
- Hoods** . . . . . 7
- Wall Ovens** . . . . . 8
- Cooktops** . . . . . 9-10



\*www.lg.com/us/support/lg-direct-service/parts-and-accessories

## What Accessories Do I Need to Purchase for My LG Gas or Dual Fuel Slide-In Range?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

### STEP 1: FIND YOUR MODEL NUMBER

LSDS6338F, LSGS6338F, LTGL6937\_(F, D), LSDL6336\_(F, D), LSGL6337\_(F, D), LSGL6335\_(F, D), LSGL5833\_(F, D), LSGL5831F



### STEP 2: READ THIS INFORMATION

<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000.	<b>Electrical Requirements</b> LG Gas Slide-in Ranges have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker, or slow blow fuse is required.	
	<b>Installation Parts Required for Gas Hookup</b>	
	<b>Anti-Tip Bracket</b> An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.	
	<b>Additional parts needed when installing on concrete floor.</b>	
	<b>LP Conversion Kit</b> If your home uses Liquid Propane (LP) instead of Natural Gas (NG), utilize the LP Conversion Kit.	

<b>Optional Accessories</b> Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000.	<b>Rear Filler</b> If the counter does not bridge the opening at the rear wall, the rear filler kit that is provided with the slide-in range, will be needed.	
	<b>Side Filler Kit (2 pieces)</b> Prevents spills or food residue from sliding in-between the range and countertop. The kit is installed with adhesive, no mounting brackets or screws needed.	
	<b>Broiler Pan and Grid</b>	
	<b>Air Fry Tray</b>	

### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

3-Prong Power Cord Attached to Unit
<input type="checkbox"/> Gas Line Shut-Off Valve <input type="checkbox"/> Joint Sealant <input type="checkbox"/> Flexible Metal Appliance Connector (3/4" or 1/2" NPT x 1/2" I.D.) <input type="checkbox"/> Flare Union Adapter for Connection to Gas Supply Line (3/4" or 1/2" NPT x 1/2" I.D.) <input type="checkbox"/> Flare Union Adapter for Connection to Pressure Regulator on Range (1/2" NPT x 1/2" I.D.)
Anti-Tip Bracket Included and Must be Installed
<input type="checkbox"/> Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)
LP Conversion Kit Included
Rear Filler Included
<input type="checkbox"/> LSFL301S Side Filler Kit
<input type="checkbox"/> Broiler Pan – Part Number Coming Soon <input type="checkbox"/> Grid Pan – Part Number Coming Soon
Air Fry Tray - LRAL303S included with slide-in ranges with Air Fry feature: LSDS6338F, LSGS6338F, LTGL6937_, LSDL6336_, LSGL6337_, LSGL6335_, LSGL5833_

## What Accessories Do I Need to Purchase for My LG Electric Slide-In Range?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

### STEP 1: FIND YOUR MODEL NUMBER

LSIS3018SS, LSES6338F, LSE4617ST, LSE4616\_(ST, BD), LTEL7337\_(F, D), LSEL6337\_(F, D), LSEL6335\_(F, D), LSEL6333\_(F, D), LSEL6331F



### STEP 2: READ THIS INFORMATION

<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000.	<b>Electrical Requirements</b> LG Electric Slide-in Ranges require a 240/208 V, 60 Hz, properly grounded dedicated circuit protected by a 40 or 50 Amp circuit breaker. A 4-wire range power cord or a 4-wire conduit connection may be used. Refer to * below if you have a 3-Prong outlet.	
	<b>Anti-Tip Bracket</b> An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.	
	Additional parts needed when installing on concrete floor.	

<b>Optional Accessories</b> Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000.	<b>Rear Filler</b> If the counter does not bridge the opening at the rear wall, the rear filler kit that is provided with the slide-in range, will be needed.	
	<b>Side Filler Kit (2 pieces)</b> Prevents spills or food residue from sliding in-between the range and countertop. The kit is installed with adhesive, no mounting brackets or screws needed.	
	<b>Broiler Pan and Grid</b>	
	<b>Air Fry Tray</b>	

### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

<input type="checkbox"/> 4-Prong Range Power Cord or a 4-Wire Conduit Connection (Refer to * below if you have a 3-Prong outlet)
<input type="checkbox"/> Strain Relief (for Conduit Installations Only)
Anti-Tip Bracket Included and Must be Installed
<input type="checkbox"/> Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)
Rear Filler Included
<input type="checkbox"/> LSFL301S Side Filler Kit
<input type="checkbox"/> Broiler Pan – Part Number Coming Soon
<input type="checkbox"/> Grid Pan – Part Number Coming Soon
Air Fry Tray - LRAL303S included with slide-in ranges with Air Fry feature: LSIS3018SS, LSES6338F, LTEL7337_, LSEL6337_, LSEL6335_, LSEL6333

\*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong range power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong range power cord. LG recommends a 4-wire connection or a 4-prong range power cord.

SS / F – PrintProof™ Stainless Steel  
  ST / S – Stainless Steel  
  D – PrintProof™ Black Stainless Steel  
  BD – Black Stainless Steel

## What Accessories Do I Need to Purchase for My LG Gas Freestanding Range?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

### STEP 2: READ THIS INFORMATION

<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button <sup>†</sup> or call 1-800-243-0000. <b>LG Parts &amp; Accessories</b>	<b>Electrical Requirements</b> LG Gas Freestanding Ranges have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker, or slow blow fuse is required.	
	<b>Installation Parts Required for Gas Hookup</b>	
	<b>Anti-Tip Bracket</b> An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.	
	Additional parts needed when installing on concrete floor.	
	<b>LP Conversion Kit</b> If your home uses Liquid Propane (LP) instead of Natural Gas (NG), utilize the LP Conversion Kit.	
<b>Optional Accessories</b> Purchase by clicking the LG parts & accessories button <sup>†</sup> or call 1-800-243-0000. <b>LG Parts &amp; Accessories</b>	Broiler Pan and Grid	
	Air Fry Tray	

### STEP 1: FIND YOUR MODEL NUMBER

LDG4313ST, LRGL5825\_(F, D), LRGL5823\_(S, D), LRGL5821S



### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

3-Prong Power Cord Attached to Unit
<input type="checkbox"/> Gas Line Shut-Off Valve <input type="checkbox"/> Joint Sealant <input type="checkbox"/> Flexible Metal Appliance Connector (3/4" or 1/2" NPT x 1/2" I.D.) <input type="checkbox"/> Flare Union Adapter for Connection to Gas Supply Line (3/4" or 1/2" NPT x 1/2" I.D.) <input type="checkbox"/> Flare Union Adapter for Connection to Pressure Regulator on Range (1/2" NPT x 1/2" I.D.)
Anti-Tip Bracket Included and Must be Installed
<input type="checkbox"/> Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)
LP Conversion Kit Included
<input type="checkbox"/> Broiler Pan – Part Number Coming Soon
<input type="checkbox"/> Grid Pan – Part Number Coming Soon
<input type="checkbox"/> Air Fry Tray - LRAL303S (For use with models with Air Fry feature: LDG4313ST, LRGL5825_, LRGL5823_, LRGL5821S)

## What Accessories Do I Need to Purchase for My LG Electric Freestanding Range?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

### STEP 2: READ THIS INFORMATION

<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button <sup>†</sup> or call 1-800-243-0000.	<b>Electrical Requirements</b> LG Electric Freestanding Ranges require a 240/208 V, 60 Hz, properly grounded dedicated circuit protected by a 40 or 50 Amp circuit breaker. A 4-wire range power cord or a 4-wire conduit connection may be used. Refer to * below if you have a 3-Prong outlet.	
	<b>Anti-Tip Bracket</b> An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.	
<b>LG Parts &amp; Accessories</b> Additional parts needed when installing on concrete floor.		
<b>Optional Accessories</b> Purchase by clicking the LG parts & accessories button <sup>†</sup> or call 1-800-243-0000.	Broiler Pan and Grid	
	Air Fry Tray	

**STEP 1: FIND YOUR MODEL NUMBER**

LDE4413ST, LREL6325\_(F, D), LREL6323\_(S, D), LREL6321S

STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER	
	<input type="checkbox"/> 4-Prong Range Power Cord or a 4-Wire Conduit Connection (Refer to * below if you have a 3-Prong outlet)
	<input type="checkbox"/> Strain Relief (for Conduit Installations Only)
	Anti-Tip Bracket Included and Must be Installed
	<input type="checkbox"/> Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)
	<input type="checkbox"/> Broiler Pan – Part Number Coming Soon
	<input type="checkbox"/> Grid Pan – Part Number Coming Soon
	<input type="checkbox"/> Air Fry Tray - LRAL303S (For use with models with Air Fry feature: LDE4413ST, LREL6325_, LREL6323_, LREL6321S)

\*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong range power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong range power cord. LG recommends a 4-wire connection or a 4-prong range power cord.

SS / F – PrintProof™ Stainless Steel
  ST / S – Stainless Steel
  D – PrintProof™ Black Stainless Steel
  BD – Black Stainless Steel

## What Accessories Do I Need to Purchase for My LG Over-the-Range Microwave?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

### STEP 1: FIND YOUR MODEL NUMBER

MHES1738F, MHEC1737\_(F, D), MVEL2137\_(F, D), MVEL2125\_(F, D), MVEL2033\_(F, D), LMV1831\_(SS, ST, BD), LMV1764ST



### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

### STEP 2: READ THIS INFORMATION



<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000. <b>LG Parts &amp; Accessories</b>	<b>Electrical Requirements</b> LG OTRs have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker is required.	
	<b>Venting Requirements</b> LG OTRs must be properly vented in one of three ways. Do not vent into a wall cavity, attic or unused area. Venting ductwork is not provided and should be purchased separately. <ol style="list-style-type: none"> <li>Roof venting with 3" 1/4 x 10" duct or 6" round duct</li> <li>Wall venting with 3" 1/4 x 10" duct or 6" round duct</li> <li>Room venting (recirculating)</li> </ol>	
<b>Installation Parts You May Need for Outside Venting</b>	<b>Roof Venting</b>	
	<b>Wall Venting</b>	
<b>Optional Accessories</b> Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000. <b>LG Parts &amp; Accessories</b>	<b>Replacement Charcoal Filter</b> LG OTRs include 1 charcoal filter for room venting installations (recirculating). It is recommended to change the filter every 6-12 months. Order an extra filter now to keep on-hand.	



<b>3-Prong Power Cord Attached to Unit</b>			
<b>Roof Venting</b> 	<b>Wall Venting</b> 	<b>Roof or Wall Venting</b> 	<b>Room Venting</b> 
<input type="checkbox"/> Duct Work (The total length of the duct system, including straight duct, elbows, transitions, and wall or roof caps must not exceed 140 feet.)			
<input type="checkbox"/> Roof Cap			
<input type="checkbox"/> Duct Tape to seal all joints			
<input type="checkbox"/> Caulking to seal the exterior roof opening around the cap			
<input type="checkbox"/> Duct Work (The total length of the duct system, including straight duct, elbows, transitions, and wall or roof caps must not exceed 140 feet.)			
<input type="checkbox"/> Wall Cap			
<input type="checkbox"/> Duct Tape to seal all joints			
<input type="checkbox"/> Caulking to seal the exterior wall opening around the cap			
<input type="checkbox"/> Replacement Charcoal Filter – Part Number Coming Soon			

## What Accessories Do I Need to Purchase for My LG Hood?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

### STEP 2: READ THIS INFORMATION

<p><b>Required Accessories</b></p> <p>Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts &amp; accessories button† or call 1-800-243-0000.</p> <p><b>LG Parts &amp; Accessories</b></p>	<p><b>Electrical Requirements</b></p> <p>LG Hoods require a 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker.</p> <p>These Hoods must be hard wired (direct wired) into an approved junction box. A plug and receptacle is not permitted on these products.</p>	
	<p>A cable locking connector (not supplied) might also be required by local codes. Check with local requirements and codes, and purchase and install appropriate connector if necessary.</p>	
	<p><b>Venting Requirements</b></p> <p>LG hoods must be properly vented in one of three ways. Do not vent into a wall cavity, attic or unused area. Venting ductwork is not provided and should be purchased separately. Use metal ductwork only. For best performance, use round ducts (6" min.) instead of rectangular, especially when elbows are required.</p> <ol style="list-style-type: none"> <li>1. Roof Venting</li> <li>2. Wall Venting</li> <li>3. Room Venting (recirculating)</li> </ol>	
	<p><b>Telescopic Duct Covers</b></p>	

<p><b>Optional Accessories</b></p> <p>Purchase by clicking the Zephyr button.</p> <p><b>Zephyr Store</b></p>	<p><b>Recirculation Kit &amp; Replacement Charcoal Filter</b></p> <p>A recirculation kit is required when venting into a room instead of outside. It is recommended to change the charcoal filter every 6-12 months. Order an extra filter now to keep on-hand.</p>	
	<p><b>Duct Cover Extension</b></p> <p>Can be used for ceiling heights that are between 9 ft. 10 in. and 12 ft.</p>	

### STEP 1: FIND YOUR MODEL NUMBER

LSHD3680ST, HCED3615\_(S, D), LSHD3080ST, HCED3015\_(S, D)



### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

- 3-Wire Circuit Connection (2-Wire with Ground)
- Cable Locking Connector
- Duct Work (The total length of the duct system, including straight duct, elbows, transitions, and wall or roof caps must not exceed 100 equivalent feet.)
- Roof or Wall Cap
- Duct Tape to seal all joints
- Caulking to seal the exterior roof opening around the cap










1 Upper and 1 Lower Duct Cover Included  
 LG hoods are designed for a max. ceiling height of 9 ft. 10 in. A duct cover extension is required for taller ceilings.

- Recirculation Kit – ZRC-01AN
- Replacement Charcoal Filter – Z0F-C091

- 12 ft. Duct Cover Extension for ceiling heights up to 12 ft. – Z1C-00AN

## What Accessories Do I Need to Purchase for My LG Wall Oven or Speed Oven?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER				
Single	Double	Combination	Speed Oven	
WSES4728F, LWS3063_(ST, BD)	WDES9428F, LWD3063_(ST, BD)	WCES6428F, LWC3063_(ST, BD)	MZBZ1715_(S,D)	
				
STEP 2: READ THIS INFORMATION				
<p><b>Required Accessories</b></p> <p>Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts &amp; accessories button† or call 1-800-243-0000.</p> <p><b>LG Parts &amp; Accessories</b></p>	<p><b>Electrical Requirements</b></p> <p>LG Wall Ovens require a 240/208 V, 60 Hz, properly grounded dedicated circuit protected by a properly sized Amp circuit breaker as noted.</p> <p>Wall Ovens must be hard wired (direct wired) into an approved junction box. A plug and receptacle is not permitted on these products.</p> <p>LG Speed Ovens require a 120 V, 60 Hz, properly grounded dedicated circuit protected by a 20 Amp circuit breaker.</p>	<p><b>STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER</b></p>		
		<input type="checkbox"/> 30 Amp Circuit Breaker with Min. #10 AWG <input type="checkbox"/> 4-Wire Circuit Connection (Refer to * below for 3-wire connection)	<input type="checkbox"/> 40 Amp Circuit Breaker with Min. #8 AWG <input type="checkbox"/> 4-Wire Circuit Connection (Refer to * below for 3-wire connection)	<input type="checkbox"/> 50 Amp Circuit Breaker with Min. #8 AWG <input type="checkbox"/> 4-Wire Circuit Connection (Refer to * below for 3-wire connection)
		<input type="checkbox"/> Junction Box		3-Prong Power Cord Attached to Unit <input type="checkbox"/> 20 Amp Circuit Breaker
		<input type="checkbox"/> Conduit Connector		Not Applicable
		<input type="checkbox"/> Wire Nuts for 10 Gauge Wiring	<input type="checkbox"/> Wire Nuts for 8 Gauge Wiring	Not Applicable
		<input type="checkbox"/> 36" of String		Not Applicable
		<input type="checkbox"/> Wood Shims		Not Applicable
	Trim Kit Included on LG STUDIO models only (WSES4728F, WDES9428F, WCES6428F)		Not Applicable	

\*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. A 3-wire connection is possible where local code permits.

SS / F – PrintProof™ Stainless Steel  
  ST / S – Stainless Steel  
  D – PrintProof™ Black Stainless Steel  
  BD – Black Stainless Steel



## What Accessories Do I Need to Purchase for My LG Gas Cooktop?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

### STEP 2: READ THIS INFORMATION

#### Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button<sup>†</sup> or call 1-800-243-0000.


[LG Parts & Accessories](#)

#### Electrical Requirements

LG Gas Cooktops have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker, or slow blow fuse is required.



#### Installation Parts Required for Gas Hookup



#### LP Conversion Kit

If your home uses Liquid Propane (LP) instead of Natural Gas (NG), utilize the LP Conversion Kit.



### STEP 1: FIND YOUR MODEL NUMBER

CBGS3628S, LCG3611\_(ST, BD), CBGS3028S, LCG3011\_(ST, BD)



### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

3-Prong Power Cord Attached to Unit

- Gas Line Shut-Off Valve
- Teflon Tape or a Thread Compound
- Pipe Fittings
- Joint Sealant
- Flexible Metal Appliance Connector (5/8" I.D.)
- Flare Union Adapter for Connection to Gas Supply Line (3/4" or 1/2" NPT x 5/8" I.D.)
- Flare Union Adapter for Connection to Pressure Regulator on Cooktop (1/4" NPT x 1/2" I.D.)

LP Conversion Kit Included

S – PrintProof™ Stainless Steel   ST – Stainless Steel   BD – PrintProof™ Black Stainless Steel

## What Accessories Do I Need to Purchase for My LG Electric Cooktop?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER			
36-INCH		30-INCH	
CBIS3618B, LSCE365ST, LCE3610SB		LSCE305ST, LCE3010SB	
STEP 2: READ THIS INFORMATION			
STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER			
<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000. <a href="#">LG Parts &amp; Accessories</a>	<b>Electrical Requirements</b> LG Electric Cooktops require a 240/208 V, 60 Hz, properly grounded dedicated circuit protected by a properly sized Amp circuit breaker as noted. A 4-wire conduit connection or power cord should be used.*		<input type="checkbox"/> 50 Amp Circuit Breaker with Min. #8 AWG <input type="checkbox"/> 4-Wire Circuit Connection (Refer to * below for 3-wire connection)
			<input type="checkbox"/> Strain Relief
			<input type="checkbox"/> Junction Box
			<input type="checkbox"/> Wire Nuts for 8 Gauge Wiring
			<input type="checkbox"/> 40 Amp Circuit Breaker with Min. #8 AWG <input type="checkbox"/> 4-Wire Circuit Connection (Refer to * below for 3-wire connection)

\*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. A 3-wire connection is possible where local code permits.

ST – Smooth Black Glass w/Stainless Trim    B / SB – Smooth Black Glass