

AS OF
DEC
2022

This quick reference guide to dishwasher accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.

Step 1 Find your model number in this guide. Model numbers that contain an underscore (_) are available in multiple colors. For example, LDTH7972_ comes in both PrintProof™ Stainless Steel (LDTH7972S) and in PrintProof™ Black Stainless Steel (LDTH7972D). LSDTS9882S does not have the underscore as it only comes in PrintProof™ Stainless Steel. Be sure to confirm availability and ordering of your color of choice.

Step 2 Read the information on accessories to determine your needs and prepare yourself by knowing the answers to the following questions.

- Do you have the required water supply?
- Do you have the ability to drain within 12 ft. of the dishwasher? (A 60" drain hose is included. If your drain exceeds this distance, you need to purchase a drain hose extension kit)
- Do you have a garbage disposal?
- Do you have the required electrical supply and a min. 15 Amp circuit?

Step 3 Identify the items you need to purchase for your dishwasher. Items with a check box need to be purchased separately.

Where to Buy?

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.*

Optional Accessories

Purchase by clicking the LG parts & accessories button* or call 1-800-243-0000.

LG Parts & Accessories

LG Dishwasher Leveling**



Contents

Dishwashers2



*www.lg.com/us/support/lg-direct-service/parts-and-accessories **<https://www.youtube.com/watch?v=yK4xsVBLbpl>

What Accessories Do I Need to Purchase for My LG Dishwasher?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000.

LG Parts & Accessories

STEP 1: FIND YOUR MODEL NUMBER

LSDTS9882S, LDTH7972_(S, D), LDPH7972_(S,D),
LDPS6762_(S, D), LDTS5552_(S, D),
LDFN4542_(SS, BD, W, B), LDFN3432T

ADFD5448AT



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

<p>Water Supply Requirements: LG dishwashers must be connected to a hot water supply with a temperature range between 120°F and 149°F. Required min. / max. water pressure is 20–80 psi.</p>		<p><input type="checkbox"/> 3/8" braided water supply hose or 3/8" copper tube with compression fitting (3/8" 90° elbow installed at factory)</p>	<p><input type="checkbox"/> 3/4" garden hose to 3/8 compression braided water supply line, 90° elbow</p>
<p>Drain Hose Requirements: Cut the included adapter so the end matches the size of the drain connection.</p>		<p>A 60" Drain Hose is attached to the dishwasher. If an extension drain hose is required, use a 5/8" or 7/8" inside diameter, 2–3 ft. length hose and a coupler for connecting the two hose ends. Do not exceed 12 ft. distance to the drain.*</p>	<p>A 60" Drain Hose is attached to the dishwasher. If an extension drain hose is required, use a 5/8" or 7/8" inside diameter, 2–3 ft. length hose and a coupler for connecting the two hose ends. Do not exceed 12 ft. distance to the drain.*</p>
<p>Electrical Requirements: A min. 15 Amp circuit is required.</p>		<p><input type="checkbox"/> 3-Wire Electric Cable</p>	<p>A power cord with a 3-prong plug is attached to dishwasher.</p>
<p>Installation Parts</p>		<p><input type="checkbox"/> Coupler</p>	<p><input type="checkbox"/> Coupler</p>
		<p><input type="checkbox"/> Coupler <input type="checkbox"/> Air Gap</p>	<p><input type="checkbox"/> Coupler <input type="checkbox"/> Air Gap</p>
<p>Misc. Installation Parts that are NOT included and should be purchased locally.</p>		<p><input type="checkbox"/> 7/8" UL Approved Strain Relief <input type="checkbox"/> Hose Clamp <input type="checkbox"/> Wire Nuts for 16-Gauge Wiring <input type="checkbox"/> Electrical Tape <input type="checkbox"/> Teflon™ Tape</p>	<p><input type="checkbox"/> 7/8" UL Approved Strain Relief <input type="checkbox"/> Hose Clamp <input type="checkbox"/> Wire Nuts for 16-Gauge Wiring <input type="checkbox"/> Electrical Tape <input type="checkbox"/> Teflon™ Tape</p>
<p>Installation Parts that are included</p>		<p>1 Hose Clamp 2 Installation Brackets 4 Wood Screws</p>	<p>1 Hose Clamp 2 Installation Brackets 4 Wood Screws Moisture Barrier Tape</p>
<p>If you want the dishwasher toe kick to match your cabinetry, you must purchase separately from a local fabricator or cabinet supplier.</p>		<p><input type="checkbox"/> Wood Toe Kick (if desired)</p>	<p><input type="checkbox"/> Wood Toe Kick (if desired)</p>

■ S / SS – PrintProof™ Stainless Steel ■ T – Stainless Steel ■ D / BD – PrintProof™ Black Stainless Steel ■ W – White ■ B – Black

* If connecting the dishwasher's drain hose to the garbage disposal, be sure to follow your garbage disposal's manual for proper installation instructions.