

AS OF  
**MAR**  
**2023**

**This quick reference guide to laundry accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.**

**Step 1** Find your model number in this guide. Model numbers that contain an underscore (\_) are available in multiple colors. For example, WM6500H\_A comes in both White (WM6500HWA) and in Black Steel (WM6500HBA). DLG3401W does not have the underscore as it only comes in White. Be sure to confirm availability and ordering of consistent model colors across washer, dryers, and pedestals if desired.

**Step 2** Read the information on required and optional accessories to determine your needs and prepare yourself by knowing the answers to the following questions.

- Gas or electric dryer?
- Side-by-side or stacked installation?
- If a side-by-side installation, do you want pedestals?
- If purchasing a gas dryer, is your home natural gas (NG) or liquid propane (LP)?

**Step 3** Identify the items you need to purchase for your washer and dryer. Items with a check box need to be purchased separately.

## Where to Buy?

### Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.<sup>†</sup>

### Optional Accessories

Purchase by clicking the LG parts & accessories button<sup>†</sup> call 1-800-243-0000.

**LG Parts & Accessories**

## Contents

<b>WashTower™ with Center Control™</b> . . . . .	<b>2</b>
<b>Front Load Pairs</b> . . . . .	<b>3</b>
29" Wide Front Load Laundry Pairs	
27" Wide Front Load Laundry Pairs	
<b>Top Load Pairs</b> . . . . .	<b>4</b>
<b>Specialty Front Load Pairs</b> . . . . .	<b>5</b>
27" All-in-One Washer / Dryer Combos	
24" All-in-One Washer / Dryer Combos	
24" Wide Compact Front Load Laundry Pairs	



<sup>†</sup>www.lg.com/us/support/lg-direct-service/parts-and-accessories

## What Accessories Do I Need to Purchase for My LG WashTower™?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

Washer w/ Electric Dryer

Washer w/ Gas Dryer

Washer w/ Heat Pump Dryer

STEP 1: FIND YOUR MODEL NUMBER	
<b>WashTower™ with Center Control™</b>	
SWWE50N3*, WKEX300HBA*, WKEX200H_A(B,W,G,R)*, WKE100H_A(V,W)	
SWWVG50N3*, WKGX301HBA*, WKGX201H_A(B,W,G,R)*, WKG101H_A(V,W)	

### STEP 2: READ THIS INFORMATION

<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.†	<b>Water Supply Requirements</b> Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20 – 120 psi.	
	<b>Dryer Electrical &amp; Venting Requirements</b> (Note: Venting ductwork is not provided and should be purchased separately, if required. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)	
	<b>LP Conversion Kit</b> If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation thorough your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)	
	<b>Optional Accessories</b> All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)	
<b>Optional Accessories</b> Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.	

### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

<input type="checkbox"/> Washer Water Supply Hoses (Hot & Cold)	
<input type="checkbox"/> Dryer Water Supply Hose (Cold) (Only Required for Steam Dryers with * in Listing Above)	Not Applicable
<input type="checkbox"/> Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)	
<input type="checkbox"/> Gas Dryers Require a Flexible Stainless Steel Gas Connector Kit	Not Applicable
<input type="checkbox"/> All Dryers Require a Transition Duct Installation Kit. (All dryers are shipped for Rear Venting)	Not Required
<input type="checkbox"/> LP Conversion Kit – 383EEL3002D (Not needed if you are ordering an LP Conversion Installation. See details on the left.)	Not Applicable
<input type="checkbox"/> Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear; Interchangeable with 383EEL9001B)	Not Applicable
<input type="checkbox"/> Drying Rack – 3750EL1001A (for WKEX300HBA, WKGX301HBA, WKEX200H_A, WKGX201H_A, WKE100H_A, WKG101H_A, WKHC202HBA)	

▲ N – Noble Steel ● V – Graphite Steel ● B – Black Steel ○ W – White ● G – Nature Green ● R – Red

\*Steam dryer †An underscore in the model number “\_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. \*\*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord. †www.lg.com/us/support/lg-direct-service/parts-and-accessories

## What Accessories Do I Need to Purchase for My LG Front Load Laundry Pair?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER		
	29" Wide Front Load Laundry Pairs	27" Wide Front Load Laundry Pairs
Washers	WM8900HBA	WM6700HBA; WM6500H_A(B,W), WM5500H_A(V,W), WM4000H_A(B,W), WM3470C_(M,W), WM3400CW
Electric Dryers	DLEX8900B*	DLEX6700B*, DLEX6500_(B,W)*, DLEX5500_(V,W)*, DLEX4000_(B,W)*, DLE3470_(M,W), DLE3400W
Gas Dryers	DLGX8901B*	DLGX6701B*, DLGX6501_(B,W)*, DLGX5501_(V,W)*, DLGX4001_(B,W)*, DLG3471_(M,W), DLG3401W

### STEP 2: READ THIS INFORMATION

Required Accessories	Water Supply Requirements	
Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button. <sup>†</sup>  <b>LG Parts &amp; Accessories</b>	Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20–120 psi.	
	<b>Dryer Electrical &amp; Venting Requirements</b> A min. 30 Amp circuit is required. (Note: Venting ductwork is not provided and should be purchased separately. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)	
	<b>LP Conversion Kit</b> If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation through your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)	



### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

Optional Accessories			
Purchase by clicking the LG parts & accessories button <sup>†</sup> or call 1-800-243-0000  <b>LG Parts &amp; Accessories</b>	When installing side-by-side, you can add 2 pedestals or 1 LG SideKick™ and 1 pedestal. (Be sure to order the correct color to match your pair.+)		<input type="checkbox"/> Pedestal – WDP5B <input type="checkbox"/> LG SideKick™ Pedestal Washer – WD200CB (Includes all Hoses and Connectors)
	When installing in a stacked configuration, you must order a Stacking Kit.		<input type="checkbox"/> Stacking Kit – KSTK2 <input type="checkbox"/> Stacking Kit – KSTK1 or KSTK4
	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)		<input type="checkbox"/> Side / Bottom Vent Kit – 383EEL9001L (Only Required if You are not Venting from the Rear) <input type="checkbox"/> Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear, Interchangeable with 383EEL9001B)
	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.		<input type="checkbox"/> Drying Rack – MGR62082001 <input type="checkbox"/> Drying Rack – 3750EL1001A (for DLEX6700B, DLGX6701B, DLEX6500_, DLGX6501_, DLEX5500_, DLGX5501_, DLEX4000_, DLGX4001_) <input type="checkbox"/> Drying Rack – 3750EL1001D (for DLE3470_, DLG3471_, DLE3400W, DLG3401W)









● V – Graphite Steel ● B – Black Steel ○ W – White ● M – Middle Black \*Steam dryer +An underscore in the model number “\_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. \*\*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. †www.lg.com/us/support/lg-direct-service/parts-and-accessories

## What Accessories Do I Need to Purchase for My LG Top Load Laundry Pair?

- Items in RED with a check box require you to make a purchase
- Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER		
	Top Load Pairs with Steam Dryers	Top Load Pairs
Washers	WT7900H_A(B,W)	WT7400C_(V,W), WT7405C_(V,W), WT7150C_(M,W), WT7155CW, WT7000CW, WT7005CW, WT6105CW
Electric Dryers	DLEX7900_E(B,W)*	DLE7400_E(V,W), DLE7150_(M,W), DLE7000W, DLE6100W
Gas Dryers	DLGX7901_E(B,W)*	DLG7401_E(V,W), DLG7151_(M,W), DLG7001W, DLG6101W
		

### STEP 2: READ THIS INFORMATION

<b>Required Accessories</b> Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.†  <span style="background-color: #e91e63; color: white; padding: 2px;">LG Parts &amp; Accessories</span>	<b>Water Supply Requirements</b> Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20 – 120 psi.	 
	<b>Dryer Electrical &amp; Venting Requirements</b> A min. 30 Amp circuit is required. (Note: Venting ductwork is not provided and should be purchased separately. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)	  
	<b>LP Conversion Kit</b> If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation through your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)	
<b>Optional Accessories</b> Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000  <span style="background-color: #e91e63; color: white; padding: 2px;">LG Parts &amp; Accessories</span>	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)	
	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.	

### STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

<input type="checkbox"/> Washer Water Supply Hoses (Hot & Cold)	
Steam Dryer Water Supply Hoses & Y-Connector Included	Not Applicable
<input type="checkbox"/> Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)	
<input type="checkbox"/> Gas Dryers Require a Flexible Stainless Steel Gas Connector Kit	
<input type="checkbox"/> All Dryers Require a Transition Duct Installation Kit	
<input type="checkbox"/> LP Conversion Kit – 383EEL3002D (Not needed if you are ordering an LP Conversion Installation. See details on the left.)	
<input type="checkbox"/> Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear, Interchangeable with 383EEL9001B)	
<input type="checkbox"/> Drying Rack – 3750EL0001C	

## What Accessories Do I Need to Purchase for My LG Specialty Front Load Laundry Pair?

Washer / Dryer Combos  
Washers  
Electric Dryers  
Gas Dryers

27" All-in-One Washer / Dryer Combos	24" All-in-One Washer / Dryer Combos	24" Wide Compact Front Load Laundry Pairs
WM3998HBA	WM3555H_A (V,W)	
-	-	WM1455HWA
-	-	DLHC1455W
-	-	-

Items in RED with a check box require you to make a purchase

Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

### STEP 2: READ THIS INFORMATION

<p><b>Required Accessories</b></p> <p>Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts &amp; accessories button.†</p> <p><b>LG Parts &amp; Accessories</b></p>	<p><b>Water Supply Requirements</b></p> <p>Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20 – 120 psi.</p>	<p><input type="checkbox"/> Washer Water Supply Hoses (Hot &amp; Cold)</p>	Hoses Included. No Additional Purchase Required.	
		<p>Steam Dryer Water Supply Hoses &amp; Y-Connector – Not Applicable</p>		
	<p><b>Dryer Electrical &amp; Venting Requirements</b></p> <p>(Note: Venting ductwork is not provided and should be purchased separately, if required. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)</p>	<p>Electric Dryer Power Cord – No Additional Purchase Required</p>	<p><input type="checkbox"/> Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)</p>	
		<p>Gas Connector Kit – Not Applicable</p>		
		<p>Ventless Condensing Dryer Does Not Require Venting</p>	Heat Pump Dryer Does Not Require Venting	
	<p><b>LP Conversion Kit</b></p> <p>If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation thorough your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)</p>	<p>Not Applicable</p>		
<p><b>Optional Accessories</b></p> <p>Purchase by clicking the LG parts &amp; accessories button† or call 1-800-243-0000</p> <p><b>LG Parts &amp; Accessories</b></p>	<p>When installing side-by-side, you can add 2 pedestals or 1 LG SideKick™ and 1 pedestal. (Be sure to order the correct color to match your pair.+) </p>	<p><input type="checkbox"/> Pedestal – WDP6B <input type="checkbox"/> ADA Pedestal (5 1/8" H) – WDPS2B <input type="checkbox"/> LG SideKick™ – WD300CB (Includes all hoses and connectors)</p>	Not Applicable	
	<p>When installing in a stacked configuration, you must order a Stacking Kit.</p>	<p>Stacking Kit - KSTK1 or KSTK4</p>	Not Stackable	Stacking Kit Included with Dryer
	<p>All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)</p>	<p>Ventless Condensing Dryer Does Not Require Venting</p>		Heat Pump Dryer Does Not Require Venting
	<p>Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.</p>	<p>Not Applicable</p>		

● V – Graphite Steel ● B – Black Steel ○ W – White \*Steam dryer +An underscore in the model number “\_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. \*\*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord. †www.lg.com/us/support/lg-direct-service/parts-and-accessories