

This quick reference guide to refrigeration accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.

Step 1 Find your model number in this guide. Model numbers that contain an underscore (_) are available in multiple colors. For example, LRMVC2306_ comes in both PrintProof™ Stainless Steel (LRMVC2306S) and in PrintProof™ Black Stainless Steel (LRMVC2306D). SRFVC2416S does not have the underscore as it only comes in PrintProof™ Stainless Steel. Be sure to confirm availability and ordering of your color of choice.

Step 2	Read the information on required and optional accessories to determine your needs and prepare
	yourself by knowing the answers to the following guestions.

- ☐ If purchasing a refrigerator with a dispenser and / or an automatic ice maker, do you have a cold water supply at the installation location?
- □ Do you have a reverse osmosis water filter system connected to your cold water supply?
- ☐ Do you have a grounded 3-prong electrical outlet within 6 ft. and a min. 15 Amp circuit?
- ☐ If purchasing a Top or Bottom Freezer Refrigerator, do you need to reverse the doors?

Step 3 Identify the items you need to purchase for your refrigerator. Items with a check box need to be purchased separately.

Where to Buy?

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.*

Optional Accessories

Purchase by clicking the LG parts & accessories button* or call 1-800-243-0000.

LG Parts & Accessories

Contents

AS OF





ACCESSORY GUIDE: 36" WIDE FRENCH DOOR INSTAVIEW™ REFRIGERATORS

What Accessories Do I Need to Purchase for My LG 36" Wide French Door InstaView™ Ice & Water Dispensing Refrigerator?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER

SRFVC2416S, LRMVS3006S, LRMVC2306_(S, D), LRFVS3006_(S, D), LRYKC2606_(S, D), LMXS28596_(S, D), LRFOC2606S



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

STEP 2: READ THIS INFORMATION

Water Supply Requirements:

LG refrigerators must be connected to a cold water supply for operation of the water dispenser and / or automatic icemaker. Required min. / max. water pressure is 20–120 psi.*

Compression nuts and ferrules are used to connect the copper tubing to the shutoff valve and the refrigerator water valve.

Shutoff valve to connect to the cold water line. A shutoff valve should have a water inlet with a minimum inside diameter of 5/32" at the point of connection to the cold water line.**

Electrical Requirements:

LG refrigerators have a 3-prong power cord attached to the unit. A grounded outlet located within 6 ft. of the unit and a min. 15 Amp circuit is required.

☐ Water Shutoff Valve

3-Prong Power Cord Attached to Unit

☐ 1/4" Outer Diameter Copper or PEX Tubing

☐ Two 1/4" Outer Diameter Compression Nuts and Two Ferrules (Sleeves)

Optional Accessories

Required AccessoriesPurchase from dealer links.

call 1-800-243-0000.

LG Parts & Accessories

in-store with unit purchase, or

if part is available, click the LG

parts & accessories button† or

Purchase by clicking the LG parts & accessories button[†] or call 1-800-243-0000.

LG Parts & Accessories

Water Filter:

Select LG refrigerators include 1 water filter. It is recommended to change the air filter every 200 gallons or approximately every 6 months. Order an extra filter now to keep on-hand.



☐ LT1000P Replacement Water Filter

Fresh Air Filter:

Select LG refrigerators include 1 fresh air filter. It is recommended to change the air filter approximately every 6 months. Order an extra filter now to keep on-hand.



☐ LT120F Replacement Fresh Air Filter

S – PrintProof™ Stainless Steel S – Stainless Steel D – PrintProof™ Black Stainless Steel Δ V – Stainless Look W – White B – Black

^{*40-60} psi min. when a reverse osmosis water filtration system is connected to the cold water supply. **Saddle-type shutoff valves are included in many water supply kits. Before purchasing, make sure a saddle-type valve complies with your local plumbing codes.



ACCESSORY GUIDE: 36" & 33" WIDE FRENCH DOOR ICE DISPENSING REFRIGERATORS

What Accessories Do I Need to Purchase for My LG 36" & 33" Wide French Door Ice & Water Dispensing Refrigerator?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER

LRMDS3006_(S, D), LRMDC2306S, LRMXS3006S, LMXS28626_(S, D), LMXC22626S, LRFDS3016S, LRYXC2606_(S, D), LRFXC2606S, LRFS28XB_(S, D), LFXC22526_(S, D), LRFXS2503_(S, D)



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

in-store with unit purchase, or

if part is available, click the LG

parts & accessories button† or

Required Accessories Purchase from dealer links,

call 1-800-243-0000.

LG Parts & Accessories

STEP 2: READ THIS INFORMATION

Water Supply Requirements:


LG refrigerators must be connected to a cold water supply for operation of the water dispenser and / or automatic icemaker. Required min. / max. water pressure is 20-120 psi.*

Compression nuts and ferrules are used to connect the copper tubing to the shutoff valve and the refrigerator water valve.

Shutoff valve to connect to the cold water line. A shutoff valve should have a water inlet with a minimum inside diameter of 5/32" at the point of connection to the cold water line.**

☐ 1/4" Outer Diameter Copper or PEX Tubing

☐ Two 1/4" Outer Diameter Compression Nuts and Two Ferrules (Sleeves)



LG refrigerators have a 3-prong power cord attached to the unit. A grounded outlet located within 6 ft. of the unit and a min. 15 Amp circuit is required.



☐ Water Shutoff Valve

3-Prong Power Cord Attached to Unit

Optional Accessories

Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000.

LG Parts & Accessories

Water Filter:

Select LG refrigerators include 1 water filter. It is recommended to change the air filter every 200 gallons or approximately every 6 months. Order an extra filter now to keep on-hand.



☐ LT1000P Replacement Water Filter

Fresh Air Filter:

Select LG refrigerators include 1 fresh air filter. It is recommended to change the air filter approximately every 6 months. Order an extra filter now to keep on-hand.



LT120F Replacement Fresh Air Filter

S - PrintProof™ Stainless Steel Stainless Steel D - PrintProof™ Black Stainless Steel V - Stainless Look W - White B - Black

^{*40-60} psi min. when a reverse osmosis water filtration system is connected to the cold water supply. **Saddle-type shutoff valves are included in many water supply kits. Before purchasing, make sure a saddle-type valve complies with your local plumbing codes.



ACCESSORY GUIDE: 36"-33" & 30" WIDE FRENCH DOOR NON-ICE DISPENSING REFRIGERATORS

LRMWS2906S, LRFWS2906 (V. S. D).

STEP 1: FIND YOUR MODEL NUMBER

What Accessories Do I Need to Purchase for My I G 36"-33" & 30" Wide French

Door Non-Ice Dispensing Refrigerator?			LMWS27626S, LFDS22520S, LRFCS29D6S, LRFCC23D6S	SRFB27S3, LRFGC2706S, LMWC23626S, LRFLC2706S	LRFCS25D3S, LFCS22520_(S, D)		
\square Items in BLACK with a c	ck box require you to make a purchase heck box are optional box are included with purchase.						
STEP 2: READ THIS INI	FORMATION		STEP 3: IDENTIFY THE ITEMS YOU NEED	TO PURCHASE FOR YOUR MODEL I	NUMBER		
Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Water Supply Requirements: LG refrigerators must be connected to a cold water supply for operation of the water dispenser and / or automatic icemaker. Required min. / max. water pressure is 20–120 psi.*	•	□ 1/4" Outer Diameter Copper or PEX Tubing				
	Compression nuts and ferrules are used to connect the copper tubing to the shutoff valve and the refrigerator water valve.		☐ Two 1/4" Outer Diameter Compression Nuts and Two Ferrules (Sleeves)				
	Shutoff valve to connect to the cold water line. A shutoff valve should have a water inlet with a minimum inside diameter of 5/32" at the point of connection to the cold water line.**		□ Water Shutoff Valve				
	Electrical Requirements: LG refrigerators have a 3-prong power cord attached to the unit. A grounded outlet located within 6 ft. of the unit and a min. 15 Amp circuit is required.		3-Prong Power Cord Attached to Unit				
Optional Accessories Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Water Filter. Select LG refrigerators include 1 water filter. It is recommended to change the air filter every 200 gallons or approximately every 6 months. Order an extra filter now to keep on-hand.	Out of the state o	□LT1000P Replacement Water Filter	Not Applicable			
	Fresh Air Filter: Select LG refrigerators include 1 fresh air filter. It is recommended to change the air filter approximately every 6 months. Order an extra filter now to keep on-hand.	LG AirFirer	Not Applicable	□LT120F Replacement Fresh Air Filter	Not Applicable		

S - PrintProof™ Stainless Steel S - Stainless Steel D - PrintProof™ Black Stainless Steel V - Stainless Look W - White B - Black

^{*40-60} psi min. when a reverse osmosis water filtration system is connected to the cold water supply. **Saddle-type shutoff valves are included in many water supply kits. Before purchasing, make sure a saddle-type valve complies with your local plumbing codes.



ACCESSORY GUIDE: SIDE-BY-SIDE REFRIGERATORS

What Accessories Do I Need to Purchase for My LG Side-by-Side Refrigerator?			STEP 1: FIND YOUR MODEL NUMBER		
			SRSXB2622S	LRSOS2706_(S, D), LRSDS2706S, LRSWS2806S, LRSXS2706_(S, V, W, B), LRSXC2306S	
☐ Items in RED with a check box require you to make a purchase ☐ Items in BLACK with a check box are optional Items in BLACK without a box are included with purchase.					
STEP 2: READ THIS INFORM	MATION		STEP 3: IDENT	IFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER	
Required Accessories	Water Supply Requirements: LG refrigerators must be connected to a cold water supply for operation of the water dispenser and / or automatic icemaker. Required min. / max. water pressure is 20–120 psi.*	. 6	□ 1/4" Outer Diameter Copper or PEX Tubing		
Purchase from dealer links, in-store with unit purchase, or	Compression nuts and ferrules are used to connect the copper tubing to the shutoff valve and the refrigerator water valve.		Two 1/4" Outer Diameter Compression Nuts and Two Ferrules (Sleeves)		
if part is available, click the LG parts & accessories button† or call 1-800-243-0000.	Shutoff valve to connect to the cold water line. A shutoff valve should have a water inlet with a minimum inside diameter of 5/32" at the point of connection to the cold water line.**		□ Water Shutoff Valve		
LG Parts & Accessories	Electrical Requirements: LG refrigerators have a 3-prong power cord attached to the unit. A grounded outlet located within 6 ft. of the unit and a min. 15 Amp circuit is required.		3-Prong Power Cord Attached to Unit		
Optional Accessories Purchase by clicking the LG parts & accessories button†	Water Filter: Select LG refrigerators include 1 water filter. It is recommended to change the air filter every 200 gallons or approximately every 6 months. Order an extra filter now to keep on-hand.		□LT700P Replacement Water Filter	□ LT1000P Replacement Water Filter	
or call 1-800-243-0000. LG Parts & Accessories	Fresh Air Filter: Select LG refrigerators include 1 fresh air filter. It is recommended to change the air filter approximately every 6 months. Order an extra filter now to keep on-hand.	LG Ai-Filter	□ LT120F Replacement Fresh Air Filter	Not Applicable	

S - PrintProof™ Stainless Steel S - Stainless Steel La V - Stainless Steel V - Stainless Steel

^{*40-60} psi min. when a reverse osmosis water filtration system is connected to the cold water supply. **Saddle-type shutoff valves are included in many water supply kits. Before purchasing, make sure a saddle-type valve complies with your local plumbing codes.



ACCESSORY GUIDE: TOP FREEZER REFRIGERATORS

What Accessories Do I Need to Purchase			STEP 1: FIND YOUR MODEL NUMBER			
for My LG Top Freezer Refrigerator?		LTCS20030S	LRTLS2403S	LTCS20020_(S, W, B)		
☐ Items in RED with a check box require you to make a purchase ☐ Items in BLACK with a check box are optional Items in BLACK without a box are included with purchase.						
STEP 2: READ THIS INFORM	1		STEP 3: IDENTIFY THE IT	EMS YOU NEED TO PURCHASE FOR	R YOUR MODEL NUMBER	
Required Accessories	Water Supply Requirements: LG refrigerators must be connected to a cold water supply for operation of the water dispenser and / or automatic icemaker. Required min. / max. water pressure is 20–120 psi.*		□ 1/4" Outer Diameter Copper or PEX Tubing	Required only if purchasing the optional ice maker.		
Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG	Compression nuts and ferrules are used to connect the copper tubing to the shutoff valve and the refrigerator water valve.		☐ Two 1/4" Outer Diameter Compression Nuts and Two Ferrules (Sleeves)	Required only if purchasing the optional ice maker.		
parts & accessories button† or call 1-800-243-0000.	Shutoff valve to connect to the cold water line. A shutoff valve should have a water inlet with a minimum inside diameter of 5/32" at the point of connection to the cold water line.**		☐ Water Shutoff Valve	Required only if purchasing the optional ice maker.		
	Electrical Requirements: LG refrigerators have a 3-prong power cord attached to the unit. A grounded outlet located within 6 ft. of the unit and a min. 15 Amp circuit is required.		3-Prong Power Cord Attached to Unit			
Optional Accessories Purchase by clicking the LG	Optional Ice Maker		Not Required. This Model has a factory-installed ice maker.	☐ LK75C Optional Ice Maker	☐ LK65C Optional Ice Maker	
parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Water Filter. Select LG refrigerators include 1 water filter. It is recommended to change the air filter every 200 gallons or approximately every 6 months. Order an extra filter now to keep on-hand.	Visitar Flate	Not Applicable	□LT500P Replacement Water Filter	Not Applicable	

S − PrintProof™ Stainless Steel S − Stainless Steel D − PrintProof™ Black Stainless Steel V − Stainless Look W − White B − Black

^{*40-60} psi min. when a reverse osmosis water filtration system is connected to the cold water supply. **Saddle-type shutoff valves are included in many water supply kits. Before purchasing, make sure a saddle-type valve complies with your local plumbing codes.



ACCESSORY GUIDE: BOTTOM FREEZER REFRIGERATORS

What Accessories Do I Need to Purchase		STEP 1: FIND YOUR MODEL NUMBER			
for My LG Bottom Freezer Refrigerator?		LRDCS2603_(S, D)	LRBCC1204S	LBNC15231V, LRBNC1104S	
☐ Items in RED with a check box require you to make a purchase ☐ Items in BLACK with a check box are optional Items in BLACK without a box are included with purchase.			5.		
STEP 2: READ THIS INFORM	IATION		STEP 3: IDENTIFY THE IT	EMS YOU NEED TO PURCHASE FO	R YOUR MODEL NUMBER
Required Accessories	Water Supply Requirements: LG refrigerators must be connected to a cold water supply for operation of the water dispenser and / or automatic icemaker. Required min. / max. water pressure is 20–120 psi.*		☐ 1/4" Outer Diameter Copper or PEX Tubing		Not required
Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG	Compression nuts and ferrules are used to connect the copper tubing to the shutoff valve and the refrigerator water valve.		☐Two 1/4" Outer Diameter Compressi	Not required	
parts & accessories button† or call 1-800-243-0000.	Shutoff valve to connect to the cold water line. A shutoff valve should have a water inlet with a minimum inside diameter of 5/32" at the point of connection to the cold water line.**		☐ Water Shutoff Valve	Not required	
LG Parts & Accessories	Electrical Requirements: LG refrigerators have a 3-prong power cord attached to the unit. A grounded outlet located within 6 ft. of the unit and a min. 15 Amp circuit is required.		3-Prong Power Cord Attached to Unit		
Optional Accessories Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Water Filter: Select LG refrigerators include 1 water filter. It is recommended to change the air filter every 200 gallons or approximately every 6 months. Order an extra filter now to keep on-hand.		☐ LT1000P Replacement Water Filter Not Applicable		

S − PrintProof[™] Stainless Steel S − Stainless Steel D − PrintProof[™] Black Stainless Steel V − Stainless Steel V − Stainless Steel V − Stainless Steel D − PrintProof[™] Black Stainless Steel V − Stainless Steel D − PrintProof[™] Black Stainless Steel D − PrintProof[™] Stainless Steel D

STEP 1: FIND YOUR MODEL NUMBER



What Accessories Do I Need to Purchase

for My LG Specialty Refrigerator? LRKNS1400V, LRONC0705A, LROFC0605V, LRONC0605V ☐ Items in RED with a check box require you to make a purchase ☐ Items in BLACK with a check box are optional Items in BLACK without a box are included with purchase. STEP 2: READ THIS INFORMATION STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER Water Supply Requirements: LG refrigerators must be connected to a cold water supply for Not required operation of the water dispenser and / or automatic icemaker. Required min. / max. water pressure is 20-120 psi.* Required Accessories Purchase from dealer links. Compression nuts and ferrules are used to connect the copper Not required in-store with unit purchase, or tubing to the shutoff valve and the refrigerator water valve. if part is available, click the LG Shutoff valve to connect to the cold water line. A shutoff valve parts & accessories button† or should have a water inlet with a minimum inside diameter of Not required call 1-800-243-0000. 5/32" at the point of connection to the cold water line.** LG Parts & Accessories **Electrical Requirements:** LG refrigerators have a 3-prong power cord attached to the 3-Prong Power Cord Attached to Unit unit. A grounded outlet located within 6 ft. of the unit and a min. 15 Amp circuit is required. **Optional Accessories** Water Filter: Purchase by clicking the LG 6 Select LG refrigerators include 1 water filter. It is recommended parts & accessories button[†] Not Applicable to change the air filter every 200 gallons or approximately or call 1-800-243-0000. every 6 months. Order an extra filter now to keep on-hand. **LG Parts & Accessories**

S - PrintProof™ Stainless Steel Stainless Steel D - PrintProof™ Black Stainless Steel V - Stainless Look W - White B - Black

^{*40-60} psi min. when a reverse osmosis water filtration system is connected to the cold water supply. **Saddle-type shutoff valves are included in many water supply kits. Before purchasing, make sure a saddle-type valve complies with your local plumbing codes.