

LG BANTER™



QWERTY Keyboard



Transferring Music



Playing Music



Bluetooth® Wireless Technology Pairing



Checking Email



Sending an Instant Message



Taking a Picture

Quick Start Guide

www.LGmobilephones.com/Banter



LG

Life's Good

Getting to Know Your Phone



1. Volume Up/Down
2. Left Soft Key (Celltop)
3. Menu/OK Key
4. Speakerphone Key
5. Talk Key
6. Camera Key
7. Voicemail Key
8. USB/Charging Port

9. microSD™ Port
10. Power/End Key
11. Clear & Back Key
12. Navigation Key
 - ▲ Alltel Web
 - ▼ Contact List
 - ◀ Music/Ringers
 - ▶ Alltel Apps

13. Right Soft Key (Message/ unlocks keypad)
14. Headset Jack
15. Status Light
16. Speaker
17. Camera Lens



QWERTY Keyboard



1. Shift Key
Change Capitalization:
Abc (Sentence Case)
ABC (ALL UPPERCASE)
abc (all lowercase)


2. Function Key
To enter alternate
characters (press
twice to lock)
3. Symbols Key
4. Space Key

5. Navigation Keys
6. OK Key
7. Clear & Back Key
8. Right Soft Key
9. Left Soft Key

Transferring Music

Your music is instantly available at your fingertips. With the optional 16GB microSD card, you can easily transfer music between your phone and PC.

1. Insert a microSD card* (gold contacts facing down) into your phone.
2. Connect a USB data cable* between the phone and your PC.
3. Select **USB Mass Storage (2)**.
4. The PC will recognize the phone as a **Removable Disk**, and a screen will appear. Drag and drop music files on your PC in the **My_Music** folder.





*microSD card and USB data cable required (sold separately).

Playing Music

No need to carry around a separate MP3 player! The integrated music player offers you ample storage space to keep the music playing on and on.

1. Insert a microSD card* containing music with the gold contacts facing down.
2. With the slide closed and the phone unlocked, press **left** on the **Navigation Key** and then press **Music (1)**.
3. Music is organized by playlists, recently played, artists, genres, and albums. Press the **MENU OK Key** to select **All Songs (1)**.
4. With the song you want to hear highlighted, press the **MENU OK Key** to begin playing that song.
5. Use the side **Volume Keys** **<** **>** to adjust the volume.

*microSD card sold separately.





Bluetooth® Wireless Technology Pairing

Bluetooth wireless technology allows you to connect easily to headsets, speakers, computers, and more. Work, chat, and listen to music without messy cords and wires!

1. Set your *Bluetooth* accessory into pairing mode.*
2. With the slide closed and the phone unlocked, press the **MENU OK** Key and then select **Settings (9) > Bluetooth (6) > Paired Devices (1)**.
3. Press the **Left Soft Key** for **Search**. If *Bluetooth* wireless technology is off, select **Yes (1)** to turn it on.
4. Select **New Search (1)**.
5. Once your *Bluetooth* device has been found, highlight it and press the **MENU OK** Key for **Pair**.
6. Enter the passcode* (typically "0000" – 4 zeroes), and then press the **MENU OK** Key.
7. Select **Yes (1)** to connect with the device.



*Refer to your *Bluetooth* accessory's user manual for information about initiating pairing mode and the passcode.



Checking Email

Checking your email anytime during your busy day is easy with this sleek phone. Slide out the four-line QWERTY keyboard and quickly begin sending and receiving email.



1. Slide out the QWERTY keyboard and select **Email (3)**.
2. Choose whether to accept the charges, and then follow the steps in the wizard to set up your email.
3. Highlight the message you want to read and press the **OK Key**. To compose an email, press the **Left Soft Key** for **New**.



Sending an Instant Message




Chat instantly and efficiently on your LG Banter using the four-line QWERTY keyboard. Instant messaging keeps you in touch without making a phone call.

1. Slide out the QWERTY keyboard and select **Instant Messaging (2)**.
2. Choose whether to accept the charges.
3. Highlight the instant messaging client you wish to use, and then press the **OK Key**.
4. Use the QWERTY keyboard to enter your screen name/ID and password, and then press the **Right Soft Key** for **Sign In**.
5. Highlight a contact that is online, and then press the **Right Soft Key** for **Send IM**.
6. Type your message, and then press the **Right Soft Key** for **Send**.




Taking a Picture

Don't miss any special moments with the LG Banter's 1.3 megapixel camera with zoom and many other customizable features.

1. With the slide closed and the phone unlocked, press and *hold* the  **Key** on the left side of your phone to access the camera viewfinder.
2. Press **left** or **right** on the **Navigation Key** to adjust the brightness. Press **up** or **down** on the **Navigation Key** to adjust the zoom.* Press the **Right Soft Key** for **Options** to access other customizable camera options.
3. Press the  **Key** to take the picture.
4. Press the  **Key** to send the photo to someone.

*Camera setting of 960 x 1280 pixels does not support zoom function.



Optional Accessories



Bluetooth® Stereo Speakers
(MSB-100)



Bluetooth Headset
(HBM-520)



Bluetooth Headset
(HBM-760)



Bluetooth Solar Car Kit
(HFB-500)



Stereo Headset



Carrying Case

Maximize your phone with these cutting-edge accessories at www.LGmobilephones.com/Banter.

All materials in this guide including, without limitation, the design, the text, and any marks are the property of LG Electronics, Inc. Copyright © 2009 LG Electronics, Inc. ALL RIGHTS RESERVED. LG is a registered trademark of LG Electronics, Inc. Features and specifications are subject to change without prior notice. The use of non-LG approved accessories will void the warranty and may result in damage to the phone, the phone exploding, or other dangerous conditions. Banter is a trademark of LG Electronics, Inc. microSD™ is a trademark of SanDisk. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics MobileComm, U.S.A., Inc. is under license. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately.



Mixed Sources

Product group from well-managed
forests and other controlled sources and
recycled wood content

www.fsc.org Cert no. XXX-XXX-XXX
© 1996 Forest Stewardship Council