

AX310



Saving and
Searching Contacts



Bluetooth® Pairing



Taking A Picture

Quick Start Guide www.lgusa.com/ax310



LG

Life's Good

Getting to Know Your Phone



1. Headset Jack
2. Volume Up/Down
3. Micro USB/Charging Port
4. Speaker
5. Camera Key
6. Camera Lens
7. Left Soft Key (Contacts)
8. Speakerphone Key

9. Send Key
10. Clear & Back Key
11. Voicemail Key
12. Shift Key
13. Microphone
14. Space/Lock Key*
15. Power/End Key
16. Menu/OK Key

17. Voice Command Key
18. Right Soft Key (Message)
19. Navigation Key
 - ^ Browser
 - > My Menu**
 - > Alltel Apps
 - < Ringtones & Ringers

*Press and *hold* this key to lock the phone.

**Customizable.

Saving and Searching Contacts


Keep your address book in the palm of your hand with the AX310.

Saving a Contact

1. Press the **Left Soft Key** for **Contacts** and then again to add a new contact.
2. Enter the contact's information using the **Keypad**.
3. Press **OK** to save the contact.

Searching for a Contact Using Phone Dial Search

1. Press the key on the **Keypad** that corresponds to the first letter in the contact's name. The phone displays the names of all relevant contacts.
2. Use the **Navigation Key** to highlight the contact's name, and press **OK** to call.




Bluetooth® Pairing

Let *Bluetooth* wireless technology set you free!
Enjoy the convenience of wireless accessories and information transfer with the AX310.

1. Place your *Bluetooth* device into pairing mode.*
2. From standby mode and with the flip open, press **OK**, then select **Bluetooth (7)**.
3. Press **OK** for **Paired Devices (1)**.
4. Press the **Left Soft Key** for **Search**. When prompted to turn on *Bluetooth*, press **OK**.
5. Press **OK** to begin a new search.
6. Once the *Bluetooth* device is found, highlight the device and press **OK** for **Pair**.
7. Once paired, press **OK** to connect to the device.

*Refer to your *Bluetooth* device's user manual for information about initiating pairing mode and the passcode if asked (typically "0000").


Note: *Bluetooth* accessories sold separately.






Taking a Picture

With your 1.3 megapixel camera, you can capture all the magic moments—and with the flip closed, you can even take self-portraits.

Flip Open

1. From standby mode, press and hold .
2. Press **up** or **down** on the **Navigation Key** to zoom.* Press **left** or **right** to adjust brightness. To adjust other camera options, press the **Right Soft Key** for **Options**.
3. Press **OK** to take the picture.


Flip Closed

1. From standby mode, press and hold , then quickly press the side **Volume Keys**  to unlock the phone.
2. Press  to take a picture.



Camera
Key

*Camera setting of 1280 x 960 pixels does not support zoom function.



Optional Accessories



Bluetooth Headset
(HFB-500)



Bluetooth Headset
(HBM-520)



Bluetooth Headset
(HBM-210)



Vehicle Power Charger



Maximize your phone with these cutting-edge accessories at www.lgusa.com/ax310.

© 2009 LG Electronics, Inc. All rights reserved. LG is a registered trademark of LG Electronics, Inc. The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics MobileComm, U.S.A., Inc. is under license. All other marks are proprietary to their respective owners. All phone images are simulated. Unless otherwise specified herein, all accessories referenced herein are sold separately.

