



www.LGUSA.com

CG225

Quick Start Guide



VGA Camera with up to 4x Zoom



Instant Messaging (IM)



Multimedia Messaging (MMS)



Downloads



Speakerphone






Getting to Know Your Phone



Taking Pictures

Capture everything around you in vivid detail through the VGA camera with up to 4x zoom*. Then share it instantly with friends via multimedia messaging.

1. From standby mode, press the **Camera Key**.
2. Press **left** or **right** on the Navigation Key to adjust brightness and **up** or **down** for zoom*. Press the **Right Soft Key** to adjust image size, self timer, multishot and other options.
3. Press  to take the picture.
4. To send your picture, press the **Left Soft Key** for **Send**. Add text to personalize your message, then press  to enter recipients. To choose a contact from your address book, press .
5. Press the **Left Soft Key** to send.

* Supports 1x, 2x or 4x depending on image size. Increasing image size will reduce the number of images stored at one time. Camera setting of 640x480 does not support zoom function.



Instant Messaging

If you subscribe to an instant messaging (IM) service such as AOL, MSN, Yahoo! or ICQ, you can take the fun and convenience of IM on the go with your mobile phone.

1. From standby mode, press **right** on the Navigation Key to access IM.
2. Highlight the IM community you want to enter and press **X**.
3. The first time you enter a community, enter your **Screen Name/ID** or **E-mail** and your **Password** and press **X**.
4. Select a contact that is currently online and press **X**.
5. Enter your message and press **X** to send. To end a chat, select **Option**, then **End Conversation (3)**.

Note: When you receive an incoming instant message, a “new message” icon similar to this one  will appear on the screen.



Screens vary by IM community.

Multimedia Messaging

Snap it. Say it. Share it. Multimedia messaging lets you share photos, voice messages and more!

1. From standby mode, press the **Left Soft Key** for **Menu**, then select **Messaging (2)**.
2. Select **New Message (1)**, then **Multimedia (2)**.
3. Write your message, then press the **Right Soft Key** for **Options**. Select **Insert (1)** and press ✕.
4. Choose **Graphic (2)** to access your photo album or **Audio (3)** to add a short audio. Select the desired photo or sound and press ✕.
5. Press ✕ to enter recipients. To choose a contact from your address book, press ✕.
6. Select a contact and press ✕. Then press ✕ again to send.



Downloadable Fun

Get access to the latest downloadable games and graphics, plus new ringtones from today's hottest artists. Personalize your phone today!

1. From standby mode, press the **Right Soft Key** for **Mall**.
2. Select **Shop Tones (1)**, **Shop Games (2)** or **Shop Graphics (3)** and press **X**.
3. When your web connection is established, choose a category, and press **X**.



Note: Downloaded files will be stored in **My Stuff (7)** under **Audio (3)** or **Graphics (4)**.

Speakerphone

Your phone includes built-in speakerphone functionality to allow for a truly hands-free conversation!

1. During a call, press the **Right Soft Key** for **Options**.
2. Select **Speaker On (1)**.
3. To deactivate, press the **Right Soft Key** for **Options**, then select **Speaker Off (1)**.



Optional Accessories

Accessories for productivity, convenience and fashion are available at www.LGUSA.com.



Mobile Charger



Vehicle Power Charger



Headset



Carrying Case



Serial Data Cable

©2006 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated.