

VX8360

Quick Start Guide





Getting Music/ Playing Music



Text Messaging Hot Key



Bluetooth® Pairing



Taking a Picture/ Recording a Video



Sending Pictures via Bluetooth



Getting to Know Your Phone Camera External Music Directional Key* Controls Dashboard with ← My Verizon) My Shortcuts Left Soft Key Right Headset Soft Kev Jack Speakerphone Key OK Key Volume Up/Down Send Key Camera Key Voice Command/ Clear & Text Voice Memo Key Back Key Messaging Hot Key Voicemail Key USB/Charging Port Power/End Key microSD™ Port

Microphone

Vibrate Mode Key

*Customizable

Getting Music/Playing Music

Rock out to your favorite tunes with the VX8360's music player. Download songs and play them anywhere!

V CAST Music with Rhapsody®

- 1. From standby mode and with the flip open, press or and then scroll to the **Media Center menu**.
- Select Music & Tones (1), and then choose V CAST Music I Rhapsody (1).
- Browse the music catalog and download songs right to your phone.

Playing Music

- 1. From standby mode and with the flip open, press or and then scroll to the **Media Center menu**.
- 2. Select Music & Tones (1), and then choose My Music (4).
- The VX8360 will automatically organize your music. With a song selected, press of to begin playing it.
- 4. Use the side **Volume Keys** to adjust the volume.
- 5. Press to exit the music player.

Note: You can also play music with the flip closed. Press and hold

once to access the music player. Press 🗾 again to begin playing music.





Text Messaging Hot Key

Keep in touch when you can't talk. Press the Text Messaging Hot Key to begin composing messages anytime you want instant. discreet communication.

- From standby mode and with the flip open, press (located to the right of the **Directional Key**) and choose your recipient(s). You can also enter numbers directly.
- Scroll down with the Directional Key to move to the Text field. Enter your message using the alphanumeric keypad, or press the Right Soft Key for Options to insert quick text, pictures, and other content.
- 3. Press OK to send your message.





Bluetooth® Pairing

Stay connected without wires or cables! Pair your VX8360 with headsets, phones, and other devices to make your life easier!

- 1. Set your Bluetooth accessory into pairing mode.*
- 2. From standby mode and with the flip open, press ok and then scroll to the **Settings & Tools menu**.
- 3. Select Bluetooth Menu (3) and then Add New Device (1).
- If Bluetooth is off, you will be prompted to turn it on by pressing or.
- 5. Press OK to begin searching for the accessory. Once it is found, highlight it and press OK to pair.*
- 6. Press OK to connect with the device.

*Refer to your Bluetooth accessory's user guide for information about initiating pairing mode and the passkey if asked (typically "0000"). If the accessory supports the headset/hands-free profile, your phone will automatically pair for you without having to input the passkey.

Note: Bluetooth accessories sold separately.





Taking a Picture/Recording a Video

Don't miss out on the perfect shot! You'll always be ready to record any moment with the VX8360's 1.3 megapixel camera and camcorder.

- To activate camera mode: From standby mode and with the flip open, press the side Camera Key
 To activate video mode: From standby mode and with the flip open, press and hold
 for 2 seconds.
- Press left or right on the Directional Key to zoom. Press up or down to adjust the brightness. Press the Right Soft Key to access additional camera/video options.
- 3. Press OK to take a photo or start/stop recording.
- 4. Press the **Left Soft Key** to save the picture/video, or press or to send it.





*Camera setting of 1280x960 pixels does not support zoom function.

Note: To take a self-portrait with the flip closed, press and hold

Press again to take a picture, or press and hold

Press again to take a picture, or press a once more to activate video mode.

Sending Pictures via Bluetooth

Why not share the pictures you've taken with others? Pair with another Bluetooth-enabled phone and send photos in a flash!

- 1. From standby mode and with the flip open, press ok and then scroll to the **Settings & Tools menu**.
- Select Bluetooth Menu (3), and then select the Bluetooth device you wish to send the picture to by pressing ok.
- Select Send Picture (5), and then mark the pictures to be sent by pressing OK.
- 4. When you're finished, press the Left Soft Key for Done.





Optional Accessories

Accessories for convenience and fashion are available at www.VerizonWireless.com.



Bluetooth Headset (HBM-760)



Bluetooth Stereo Headset



Bluetooth Stereo Speakers



Vehicle Power Charger



Extended Battery (1,500 mAh)



Portable Stereo Speakers

All materials in this datasheet including without limitation, the design, the text, and any marks are the property of LG Electronics, Inc. Copyright © 2008 LG Electronics, Inc. ALL RIGHTS RESERVED. All other marks are proprietary to their respective owners. Features and specifications are subject to change without prior notice. The use of non-LG or non-Verizon Wireless approved accessories will void the warranty and may result in damage to the phone, the phone exploding, or other dangerous conditions, microSD[™] is a trademark of SanDisk. The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SiG. Inc. and any use of such marks by LGE Mobile Comm. USA is under license.

