

How can I calibrate the oven temperature? (1/2)

① Please check the type number of your model on Model Table.

- For example, LRGN6325X → LRGN6325* → Type 3

* Model Table

Calibration Setting Types							
Type	Model Name			Type	Model Name		
1	LRGL5821*	LREL6321*		6	LDE4411*	LDE4413*	LDE4415*
2	LRGL5823*	LREL6323*			LDG4311*	LDG4313*	LDG4315*
	LRGL5825*	LREL6325*	LRE4211*		LDG5315*	LDE5415*	LDGL6924*
	LRE4213*	LRE4215*	LRG4111*		LDEL7324*		
3	LRG4113*	LRG4115*	LSGL6335*	7	LUTE4619*	LTE4815*	LUTD4919*
	LSGL6337*	LSEL6335*	LSEL6337*		LUTG4519*	LTG4715*	
	LSGS6338*	LSES6338*	LRG5115*	8	SKSGR360*	SKSGR480*	SKSDR480*
	LSDS6338*	LSIS6338*	LSIL6336*		SKSDR360*		
	LREN6325*	LRGN6325*		9	LRG3081*		
4	LSGL5833*	LSEL6333*	LSSE3029*	10	LRG3060*	LRG3061*	LSGL5831*
	UPSE3024*	LSE4617*	LSSE3030*		LSIL633T*	LSIL6332*	LSIL633C*
	LSIS3018*	LSSG3019*	UPSG3014*		LREN6321*	LRIN6323*	LRGN6323*
	LSSG3020*	LSSG3016*	LSSE3026*	11	LRG3193*	LSIL6334*	LSEL6331*
	LSE5615*	LSEL633C	LSGL583C		LSEL6332*	LREN6323*	
5	LSE4611*	LSE4613*	LSE4616*	12	LRG3194*		
	LSE4615*	LSG4513*	LSG4511*	13	LRE6383*	LRE3060*	LRE3061*
	LSG4515*	LSD4913*	LSG5513*		LRE3193*	LRE3194*	LRE3083*
	LSE5613*				LRE3163*		
				14	LTEL7337*	LTGL6937*	LTIS7338*

How can I calibrate the oven temperature? (2/2)

② Please check the type number on Calibration Procedure table.

How to Adjust the Oven Thermostat (Calibration Procedure)						
Type	Step 1	Step 2	Step 3	Step 4		Step 5
	Preparation	Enter Setup State	Enter Calibration Setting State	Enter Amount Of Temperature	Select Increase Or Decrease	Completion
1	-	Press Settings .	Press Settings repeatedly until AdJU appears.	Press or press hold plus(+) or minus(-) as desired amount.	Press Settings to add a minus sign.	Press START to accept the change.
2	-	Press and hold Clock for 3 seconds.	Press Clock repeatedly until AdJU appears.			
3	-	Press Settings .	Press Settings repeatedly until AdJU appears.			
4	Set the oven mode knob to the OFF position.	Press and hold Start Time for 3 seconds.	Press Start Time repeatedly until AdJU appears.	Press or press hold plus(+) or minus(-) as desired amount.		
5		Press Setting .	Press Setting repeatedly until AdJU appears.			
6	-	Press Settings .	Press Settings repeatedly until L_AJ or U_AJ Appears.	Use the number keys(buttons) to enter the number of desired degrees.	Press Settings to add a minus sign.	
7	-	Press and hold Start Time for 3 seconds.	Press Start Time repeatedly until L_AJ or U_AJ Appears.	Press or press hold plus(+) or minus(-) as desired amount.		
8	-	Touch Settings at the main screen.	Swipe to the third setting screen and touch Thermostat Adjustment .	Drag indicator or tap a location on the scale or tap&hold +/- to scroll up/ down		Touch OK .
9	-	-	Press and hold Bake for 3 seconds.	Press or press hold plus(+) or minus(-) as desired amount.		Press START to accept the change.
10	-	Press Settings .	Press Settings repeatedly until AdJU appears.			
11	-	Press and hold Clock for 3 seconds.	Press Clock repeatedly until AdJU appears.			
12	-	Press and hold Timer On/Off for 3 seconds.	Press Timer On/Off repeatedly until AdJU appears.			
13	-	Press Setting .	Press Setting repeatedly until AdJU appears.	Use the number keys(buttons) to enter the number of desired degrees.	Press Setting to add a minus sign.	
14	-	Press and hold Start Time for 3 seconds.	Press Start Time repeatedly until L_AJ or U_AJ Appears.	Use the number keys(buttons) to enter the number of desired degrees.	Press Start Time to add a minus sign.	