



Why LG Comfort Kits?

LG Comfort Kits make everyday appliance use easier and more comfortable. They attach in minutes—no tools required.

AAA30793450

Easy Handle for Doors



Makes it easier to open the door for anyone who may find gripping challenging

Compatible with:

Washers

WM6700, WM6500, WM5800, WM5700, WM5500, WM4200, WM4080, WM4000

WashCombo™

WM6998

WashTower™

WKEX300/WKGX301, WKEX200/WKGX201, WKE100/WKG101, WKHC252, WSEX200/WSGX201, SWWE50N3/SWWG50N3, SWWE50W4/SWWG50W4

Dryers

DLEX6700/DLGX6701, DLEX6500/DLGX6501, DLEX5800/DLGX5801, DLEX5500/DLGX5501, DLEX4200/DLGX4201, DLEX4080/DLGX4081, DLEX4000/DLGX4001, DLHC5502

AAA30793452

Easy Handle for Drawers



Attaches directly to the dispenser drawer to make it easier to slide open

Compatible with:

Washers

WM6700, WM6500, WM5800, WM5700, WM5500

WashCombo™

WM6998

WashTower™

WKEX300/WKGX301, WKEX200/WKGX201, WKE100/WKG101, WKHC252, WSEX200/WSGX201, SWWE50N3/SWWG50N3, SWWE50W4/SWWG50W4

AAA30793454

Easy Ball for Dials



Simply snaps in place around the dial to make turning the dial easier

Compatible with:

Washers

WM6700, WM6500, WM5800, WM5700, WM5500

WashCombo™

WM6998

Dryers

DLEX6700/DLGX6701, DLEX6500/DLGX6501, DLEX5800/DLGX5801, DLEX5500/DLGX5501, DLHC5502



Life's Good.