



# Get to Know Your Phone

## Setting Up Your Phone

Welcome to Verizon Wireless. You're now part of a growing movement that's about speed, signal and strength. This guide will show you how to set up and use your phone, access special features, and find help.

### Step 1. Remove the Back Cover

Place your fingernail in the cutout at the bottom of the phone and pop the cover off the phone.



### Step 2. Insert the Battery

Insert the battery, making sure to align the gold contacts. Press down gently to secure the battery.



### Step 3. Replace the Back Cover

Place the back cover over the back of the phone and press down along the edges to secure it.



### Step 4. Charge the Phone

Before turning on your phone, charge it fully.

1. Connect the USB cable to the charger adapter.
2. Plug the other end of the USB cable to the USB/Charging Port and the charger adapter into an electrical outlet.

CAUTION! Please use only an approved charger to charge your phone. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.



USB cable

NOTE: Please make sure that the "Ψ" side faces up before inserting a charger or USB cable into the USB/Charging Port of your phone.



- 1 Earpiece
- 2 Main LCD Screen
- 3 OK Key/ Directional Key
- 4 Left Select Key
- 5 Message Key
- 6 Headset Jack
- 7 Volume Keys
- 8 SEND Key
- 9 USB/ Charging Port
- 10 International Call Prefix Key
- 11 Microphone
- 12 Vibrate Mode Key
- 13 Keypad
- 14 Clear/Voice Commands Key
- 15 Power/END Key
- 16 Camera Key
- 17 Speakerphone Key
- 18 Right Select Key
- 19 Alarm Key

NOTE: Devices and software are constantly evolving—the screen images and icons are for reference only.

## Using Your Phone

### Turning Your Phone On/Off

- Press and hold the **Power/END** key to turn your phone on.
- Press and hold the **Power/END** key to turn your phone off.

### Home Screen

Below is the default Home screen. To access the options at the bottom, use the **Left** and **Right** Select keys and the **OK** key.




- 1 Camera
- 2 Front LCD Screen
- 3 Back Cover
- 4 Battery




## Making a Call

Open the phone and enter the phone number using the keypad.


 Press the **SEND** key to dial the number.


 Press the **Power/END** key to end the call.

NOTE: Your phone has a Voice Commands feature that also lets you make calls by saying a phone number or Contact name. To access it, press the **Voice Commands key**  and say **Call** followed by the name or number.


## Receiving a Call


When the phone rings or vibrates, you can answer the call by simply opening the phone. If the phone is already open, answer the call by pressing any key.


 To end the call, simply close the phone or press the **Power/END** key.

To add more answer options, press the **OK key**  **MENU**. Then select **Settings & Tools > Call Settings > Answer Options** and unmark **Flip Open**.


Then, when the phone rings, you will be able to:

 **Quiet** Mute the ringing or vibration for a call by pressing the **Left Select key**.

 **Ignore** Send the call directly to Voice Mail by pressing the **Right Select key**.


 **TEXT** End the call and send a quick text message to the caller by pressing the **OK key**.

## Setting Up Voice Mail

1. Dial **\*86** and press the **SEND key** .
2. Follow the setup instructions.

## Checking Voice Mail

From your phone:

1. Dial **\*86** and press the **SEND key** .
2. Follow the instructions.

From other phones:






1. Dial your wireless number.
2. When you hear the greeting, press **#** to interrupt.
3. Follow the instructions.

NOTE: Voice mailboxes not set up within 45 days will be canceled. Your voice mailbox is not password protected until you create a password by following the setup tutorial.

## Text Messaging








Send text, picture and voice messages from your phone. Depending on the type of message you choose to send, you can also

attach files to your messages including pictures, sounds, voice recordings and name cards.

1. Open the phone and press the **OK key**  **MENU**.
2. Press  **Messaging**.
3. Press  **New Message**.
4. Press the **OK key**  to access the text field.
5. Use the keypad to enter your message.
6. Press the **OK key**  **SEND**.

## Taking Photos





Take digital pictures with your phone.

1. Open the phone and press the **OK key**  **MENU**.
2. Press  **Media Center**.
3. Press  **Pictures**.
4. Press  **Take Picture**.
5. Set the brightness by pressing the **Directional key**  up and down, zoom by pressing the **Directional key**  left and right, and press the **Right Select key**  **Options** to change other settings.

NOTE: Zoom is not available at the highest resolution.

## Turning Bluetooth On/Off

To turn your phone's Bluetooth® On/Off:

1. Open the phone and press the **OK key**  **MENU**.
2. Press  **Settings & Tools**.
3. Press  **Bluetooth Menu**.
4. Press the **Left Select key**  **Turn On**.

NOTE: By default, your device's Bluetooth® is turned off.



## Backup Assistant<sup>SM</sup>

You can save your phone's address book to a secure website. If your phone is lost or damaged, or if you upgrade to a new phone, Backup Assistant will restore your contacts. Go to [verizonwireless.com/baplus](http://verizonwireless.com/baplus).

NOTE: Subject to specific terms of use. See [verizonwireless.com/baplus](http://verizonwireless.com/baplus) for details.

## Internet

Take the Internet with you on the go. You can reach the latest news, weather and stock reports from your phone.

1. Open the phone and press the **OK key**  **MENU**.
2. Press  **Internet** to start surfing the web.

## Support & More

### My Verizon



Manage your account, track your usage, edit account information, pay your bill and more at [verizonwireless.com/myverizon](http://verizonwireless.com/myverizon).

### Get Help Using Your Phone



From your computer, visit [verizonwireless.com/support](http://verizonwireless.com/support).

### Customer Service



Call **(800) 922-0204**.

Follow us [@VZWSupport](https://twitter.com/VZWSupport). 

### More Information



Download a User Guide from [support.vzw.com/phones](http://support.vzw.com/phones) or call **(877) 268-7589** to order a copy.

## Customer Information

### Your Wireless Device and Third Party Services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products including any personal information you choose to use, submit or share with others. Specific third party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

### Hearing Aid Compatibility Information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult Verizon Wireless or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult Verizon Wireless or the phone retailer.